



TRK-240 Programming & Installation Guide

**TRK-240 Mobile Display/Status Terminal
With Optional Peripherals
Hardware Versions 1 & 2**

CES WIRELESS TECHNOLOGIES

925-122 S. Semoran Blvd
Winter Park, FL. 32792 USA
Tel: 407-679-9440 Fax: 407-679-8110
Email: support@ceswireless.com
Web: www.ceswireless.com

MAN 104 Version 6.75
August, 06
Printed in USA

Table of Contents

WARRANTY AND COPYRIGHT INFORMATION.....	5
1.0 INTRODUCTION.....	6
2.0 RADIO INTERFACE.....	8
RADIO APPLICATION/INTERFACE NOTES.....	8
BEFORE INSTALLING	8
SERIAL INTERFACE.....	8
ANALOG INTERFACES	8
<i>Required Equipment for Installation.....</i>	8
<i>Wiring Chart.....</i>	9
3.0 PROGRAMMING.....	17
SETTING UP THE COMPUTER	17
INSTALLING TRK-240S SOFTWARE.....	17
4.0 SOFTWARE OPERATION.....	18
TRK-240S FLOW CHART	19
INITIALIZE SOFTWARE.....	20
FILE	22
<i>Open.....</i>	22
<i>Save.....</i>	22
<i>Save As.....</i>	22
<i>Edit Comment Field.....</i>	22
<i>Print.....</i>	22
<i>Exit.....</i>	22
DEVICE	23
<i>Set to Defaults.....</i>	23
<i>System Parameters.....</i>	23
<i>TRK-240 Predefined Messages (Outbound).....</i>	23
<i>TRK-240 geo-STATUS™.....</i>	23
<i>TRK-240 Legends/Sub Menus.....</i>	23
<i>Auxiliary Inputs.....</i>	23
CONFIGURE.....	24
<i>Com Port.....</i>	24
<i>Verify Mobile Connection.....</i>	24
PROGRAM.....	24
<i>Set Unit to factory Defaults.....</i>	24
<i>Get Unit Configuration.....</i>	24
<i>Send Unit Configuration.....</i>	24
<i>Compare Unit Configuration.....</i>	24
<i>Get Serial Number.....</i>	24
<i>Get Product ID.....</i>	24
<i>Begin Sequential Programming.....</i>	24
<i>Configure CDPD Radio.....</i>	25
HELP	25
<i>About.....</i>	25
5.0 TRK-240 SYSTEM PARAMETERS.....	26
RADIO	26
<i>System ID.....</i>	27
<i>Unit ID.....</i>	27
<i>Group ID.....</i>	27
<i>Radio Interface.....</i>	27

Baud Rate	27
Radio Type	27
Lead In delay	29
Busy/Request Check or Request Check	29
Request Window	29
Grant Check	29
Grant Window	29
Note: These settings are typical, however some radios differ slightly from this.	30
Encryption	30
Busy	30
Frame Transmit	31
CHANNEL CHANGE	32
Channel Change – Before Data is Sent	32
Channel Change – After Data is Sent	33
Acknowledgements	34
Decrement retries on channel access error	34
Enable Strip Turn Off Code on Aux out 1	34
PASSPORT - Registration Input (Aux In 1)	34
I/O (INPUTS & OUTPUTS)	35
Output Polarity	35
Speaker Mute Active During	36
Talk Mode	37
Horn	37
Input Polarity	37
Emergency	38
SERIAL	39
Serial Port Assignment	39
CDPD	41
Printer	41
CDPD/GPRS/CDMA	42
CDPD Only	42
GPRS/CDMA Only	42
GSM	42
GPS	43
Basic GPS Functions	43
Compressed Sending	45
Timed Sending	45
Compressed Sending	45
Compressed Timed Sending	46
Compressed Event Sending	46
MOTION-trak™	47
Datum	47
ANI / STATUS	48
ANI (Automatic Number Identification)	48
ANI Holdoff	49
PTT Functions	49
MESSAGE QUEUE	50
Long Term Queue	50
Short Term Queue	50
Remote Key Masking	51
Display / Audio Functions	51
STATUS KEYS	52
PREDEFINED MESSAGES	55
GEO-STATUS	56
TRK-240 LEGENDS	59
TRK-240 AUXILIARY INPUTS	60
Input Type Selections	60
DIAGNOSTICS	61

<i>Test Modes</i>	61
<i>GPS Test Mode</i>	62
<i>Radio Status</i>	62
<i>Firmware</i>	62
<i>Reset Unit</i>	63
6.0 LOCAL DIAGNOSTIC MODE	64
1 RADIO STATUS	64
2 PROGRAM MODE	64
<i>To Program an Item</i>	64
3 TEST OUTPUTS	64
<i>Modem Selections</i>	65
<i>Alert/Horn Selections</i>	65
<i>Display Selections</i>	65
<i>Radio Output Selections</i>	65
<i>Aux Output Selections</i>	65
4 VIEW STATES	65
<i>Frame Selections</i>	66
<i>System Selections</i>	66
<i>User I/O Selections</i>	66
<i>Radio Input Selections</i>	66
5 IDENTITY	66
6 NMEA GPS.....	66
7 LEVELS (TRK-240 VERSION 2 HARDWARE ONLY)	67
<i>Level Selections</i>	67
8 MEMORY (TRK-240 VERSION 2 HARDWARE ONLY)	67
RESET.....	67
EXIT	67
7.0 LIST OF SUPPORTED KEYBOARD PROGRAMMING ITEMS	68
SPECIFICATIONS	79
9.0 IN CASE OF DIFFICULTY	81
10.0 AMENDMENTS	82
11.0 CIRCUIT DIAGRAM	83
12.0 PARTS LOCATION	1

Warranty

CES Wireless Technologies Corp., (CES), warrants this product to be free from defects in material and workmanship for two years from date of shipment. If such malfunction occurs, it will be repaired or replaced (at our option) without charge for materials or labor if returned to the factory. This warranty does not apply to parts damaged due to improper use- including accident, neglect, unreasonable use, and improper installation - or to unauthorized alterations or modifications of the equipment. It does not extend to damage incurred by natural causes such as lightening, fire, floods, or other such catastrophes, nor to damage caused by environmental extremes, such as power surges and or transients. It does not extend to microprocessors if it is determined that the failure of a micro is due to static damage, application of improper voltages to the unit, or other problems not related to circuit design. In such case or in the case of a desire to update the micro to a different version of software, such request must be specified in writing, and there will be a charge agreed upon by both parties.

This product is warranted to meet published specifications and to operation as specified only when properly installed in radio equipment which complies with US FCC specification and the applicable radio manufacturer's specifications. CES WIRELESS is not responsible for any operational problems caused by system design, outside interference, or improper installation. A qualified two-way radio technician or engineer must complete installation and programming of this CES WIRELESS product.

Equipment for repair must be returned to the factory, freight prepaid, only with prior authorization. Please call 407-679-9440 for an RMA number. A brief letter describing the nature of the defect should be included with the merchandise. Repair by other than CES WIRELESS will void this warranty. In-warranty merchandise must be shipped, freight prepaid, to CES WIRELESS. CES WIRELESS will return the repaired or replaced equipment prepaid to purchaser, within the United States. Outside the US the customer must pay freight.

This warranty applies to the original purchaser of the equipment only. CES WIRELESS is not liable under this warranty, or any implied warranty, for loss of use or for other consequential loss or damage experienced by the purchaser. Some states do not permit the exclusion or limitation of implied warranties or consequential damages. This warranty provides special legal rights, and the purchaser may have other rights that vary from state to state.

Copyright

The information in this manual and any software in this product remain the property of CES WIRELESS. Duplication or disclosure is not permitted without the prior written consent of CES WIRELESS. CES WIRELESS reserves the right to change products, specifications, and installation data at any time, without notice.

All information contained in this document is carefully prepared and offered in good faith as a guide in the installation, operation, use and servicing of our products. Installers must insure that the final installation operates satisfactory, within relevant regulatory requirements. We accept no responsibility for incorrect installations.

AR/STTM and autoCALLTM are trademarks of CES
LTRTM is a registered trademark of E.F. Johnson Company
Smartnet is a trademark of Motorola Communications
Windows and Windows '95 is a registered trademark of Microsoft
IBM is a trademark of International Business Machines
Tracker IITM and zone-CALL TM are trademarks of CES WIRELESS
iDEN is a registered trademark of Motorola Communications

CES WIRELESS PUBLICATION Copyright CES WIRELESS 1997-2004

1.0 Introduction

We are very pleased that you have selected the CES WIRELESS TRK-240 Mobile Display Terminal. As a manufacturer, we are committed to providing complete satisfaction. If you have any questions or concerns, we will guarantee you complete satisfaction through direct assistance from our factory.

This manual is designed for the radio dealer, system engineer or installation technician who will configure and install the customers mobile data system. A separate “user” manual is available. Optionally, CES WIRELESS will provide a customized “user” manual after the programming options have been agreed upon.

CES WIRELESS offers a wide range of mobile data products and peripheral devices. For maximum benefit, please read this manual carefully before commencing programming or installation.

This manual provides complete details on the programming of the TRK-240 Mobile Status & Display Terminal. There are over 500 programmable parameters in the TRK-240. It is easy to become over zealous by introducing many of these into a system without a concern for what the customer wants. We ask you to exercise caution, and consult the customer before introducing a level of functionality that defeats the purpose of the system. As always, each mobile terminal must be compatible with the base equipment and base software.

Because we are engaged in a program of continual product development, the specifications and descriptions outlined in this manual are subject to change. Please consult the amendment section for changes. As a result of our product improvement program, there are two version of the TRK-240. These can be identified easily on the power up screen or Product ID.

Power up screen Version 1	Display Line 1 reads	TRK-240
Power up screen Version 2	Display Line 1 reads	TRK-240 Ver 2
Product ID Version 1	06000823	
Product ID Version 2	06000833	

The TRK-240 is designed to provide fixed status signaling together with display messaging. Optional peripherals include GPS automatic vehicle location; credit card reader, bar code scanner, Qwerty keyboard or mobile printer is also available. A high level of functionality is provided together with ease of installation.

This product has been carefully engineered and manufactured to provide reliable service in virtually any wireless communications system. Occasionally, particular systems may require special functions not available in standard products. Please call your CES WIRELESS Applications Engineer to discuss special applications to meet other needs.

At CES, we strive to bring you products that meet your needs. If you have any comments about our products, manuals or service please call 407 -679-9440, and thank you for your continued support.

Important Notes:

1: The programming and use of TRK-240 features and functions are dictated for the most part by the system application. Some features and options are mutually exclusive. Please contact CES WIRELESS to discuss your application prior to programming the device.

2: There are two version of the TRK-240, referenced throughout this manual as Version 1 and Version 2.

These can be identified easily on the TRK-240 power up screen (or Product ID) as follows.

Power up screen Version 1	Display Line 1 reads	TRK-240
Power up screen Version 2	Display Line 1 reads	TRK-240 Ver 2
Product ID Version 1	06000823	
Product ID Version 2	06000833	

3: To program, the TRK-240 Version 1 board uses the ARI-199P. The TRK-240 Version 2 board uses the TRK-240PA adapter or the TRKPGMR.

4: The following are the data frequencies generated by the TRK-240.

600 baud	600Hz/900Hz
1200 baud	1200Hz/1800Hz
2400 baud	1200hz/2400Hz

2.0 Radio Interface

A qualified two-way radio technician or engineer must complete the interface and programming of this CES WIRELESS product. CES WIRELESS is not responsible for any operational problems caused by system design, outside interference, or improper installation. Observe normal static prevention practices.

Radio Application/Interface Notes

Application Notes for selected radio models may be obtained by contacting your CES WIRELESS sales representative or from the CES WIRELESS web site. If not available, CES WIRELESS, at a nominal charge will prepare an application note for you. Please contact CES WIRELESS at 407-679-9440 for further information.

Before Installing

The *TRK-240* may be interfaced to almost any mobile radio. The *TRK-240* terminal should be programmed prior to field installation. CES Wireless recommends that 1-5 units, together with the base, be programmed and installed before proceeding with the complete fleet installation. We further recommend that all infrastructure, peripherals, modifications, and any and all components that are required for the successful system operation be installed prior to proceeding with the full fleet installation. This is to insure that all settings and configurations are properly set and optimized before programming and installing of all of the mobile units. CES Wireless will not entertain any claims that may arise due to incorrect programming or installation, or programming or installation that varies from our recommendations.

Serial Interface

Please see the amendment section if the TRK-240 will be interfaced to a 'data' ready radio using a serial interface. Current interfaces include various Motorola transceivers, Motorola iDEN™, Sierra Wireless, Uniden, Novatel CDPD, TMI satellite, EMS satellite transceivers. Your CES WIRELESS sales or support executive can provide you with additional information.

Analog Interfaces

The following sections describe the interface of the TRK-240 to a conventional or trunked radio.

Required Equipment for Installation

- Communications service monitor and deviation meter with oscilloscope
- Temperature-controlled soldering iron (fine tip, if surface mount components are used in radio)
- Oscilloscope
- Volt-ohm-meter
- Flat blade (3/64" width) screwdriver or similar alignment tool

Wiring Chart

The TRK-240 contains two wiring looms, one for Radio connection and one for Auxiliary connections.

Radio Interface Connector DB-25

CONNECTOR PIN ASSIGNMENTS

Pin	Function	Type	Notes	Direction
1	Power	8-16v	Switched B+ (+8 volts to +16 volts DC) with 1 Amp fuse. Connect to a 8 to 16 volt switched and fused source. Most radios with an accessory connector provide a switched 12 volt source for the accessory. Use this output providing it is capable of at least 1 amp of current.	
2	Ground		Radio Ground (Connect to any good ground.)	
3	Receive audio	Audio	Input Audio, Z = 67K or 20K, cap coupled It is recommended that receive audio be obtained from a flat un-muted audio source. In most cases this will be the receiver's discriminator. Radios with accessory connectors usually provide such a source. With an oscilloscope, verify that there is no loading of the discriminator with the TRK-240 connected. If loading occurs or the receive audio is too high and difficult to adjust, remove JP2 inside the TRK-240. This increases the receive audio input impedance. Sometimes an additional external resistor is required. See <i>TRK-240 Adjustments</i> for the Rx audio adjustment procedure.	Input
4	Transmit audio	Audio	Modulator with pre-emphasis, Z = 47K or 10K, cap coupled It is recommended that this output be connected to a point after the microphone pre-emphasis circuit. Most radios with an accessory connector provide a flat audio injection point. After making this connection verify that there is no loading of the microphone or signaling (CTCSS/DCS) levels. If loading occurs or the data level is too high and difficult to adjust, remove JP3 inside the TRK-240. This increases the transmit output impedance. Sometimes an additional external resistor is required. See <i>TRK-240 Adjustments</i> for the Tx audio adjustment procedure.	Output
5	Ground			
6	Speaker enable	OC	Audio Power Amplifier Enable (Hardware Version 1) Open collector, no pull up. (Hardware Version 2) Open collector, with removable pull up. This logical function may be required to turn on the receiver audio circuitry, as would normally be disabled or muted while the radio is in a transmit condition - applicable only if the Alert Tone is being used and a speaker/audio amplifier input is required to enable the audio circuits. The active state of this output is programmable.	Output

7	Mic mute	OC	<p>(Hardware Version 1) Open collector, no pull up.</p> <p>(Hardware Version 2) Open collector, with removable pull up.</p> <p>This connection is only required if Leading or Random ANI will be used. This connection is used to mute the local microphone while data is being sent. This connection must not effect the data injection point. Some radios with accessory connectors provide such a connection. The active state of this output is programmable.</p>	Output
8	Auxiliary out R	OC	<p>(Hardware Version 1) Open collector, no pull up.</p> <p>(Hardware Version 2) Open collector, with removable pull up.</p> <p>This open collector output is normally used for channel steering. Some radios provide inputs for channel or group steering. Alternately this wire can sometimes be connected to the channel up or down circuitry in the radio. This output can also be used to strip CTCSS or DCS signaling during data transmissions. This may aid in keeping the data muted. See <i>Channel Change</i> for additional information about Channel Steering. The active state of this output is programmable. Maximum Sink Current 300ma.</p>	Output
9	PTT in	-35 to 35v	<p>Logic input, Z =100K, -35V to +35V</p> <p>This input should be connected to a point that provides local microphone activity. When this input is active the TRK-240 will not send data (excluding ANI). This input may be connected to the same point as the PTT Out wire. Alternatively, if it is required that the TRK-240 be in complete control of the Transmitter, in other words provide busy channel lockout, trailing ANI or closed mode operation, a modification to the radios PTT circuitry will be required. The local microphone's PTT signal must be isolated from the TX circuitry. Generally a PC board trace must be cut to do this. Connect the PTT In wire to the microphone side of the cut and the PTT Out wire on the other side of the cut. This puts the TRK-240 circuitry in series with the radio's PTT circuitry.</p>	Input
10	Auxiliary in R	-35 to 35v	<p>Logic input, Z = 100K, -35V to +35V.</p> <p>Used for Channel Change prior to firmware version 5.49. Used as additional Busy input after firmware version 5.48 (<i>subject to change with custom firmware</i>).</p> <p>The standard function for this input is to detect channel activity when set to LTR or Smartnet operation. This input when active can force the TRK-240 to hold off sending data transmissions. Connect this wire to a point that changes state when the squelch switch is open. This input is not required for conventional mode operation. The active state of this input is programmable.</p>	Input

11	Conventional/ Trunked	-35 to 35v	<p>Busy/Channel Ready Logic, Z = 100K, -35V to 35V</p> <p>The Radio Type selected determines the function of this input. It functions as a busy channel input when in conventional mode, and a channel available (Clear to Send) input when in a trunked mode. For conventional only operation, connect this wire to a point that changes state when the receivers squelch is open. For trunked only or trunked with conventional mode operation, connect this wire to TX volts or the Clear to Send signal if available. On some radios the Clear to Send signal only functions in trunked modes. If the system involved is a combination of trunked and conventional repeaters this wire may need to be connected to TX volts or any signal that indicates transmitter activity. The active state of this input is programmable.</p>	Input
12	Alert	Audio	Receiver audio power amplifier, Z = 67K, cap coupled (see Note 1).	Output
13	PTT out	OC, diode	<p>Push to talk output, Open collector, no pull up</p> <p>Connect this wire to a point that will key the radio to send data. Also see "PTT In". The active state of this output is programmable.</p>	Output
14	Speaker mute	OC	<p>(Hardware Version 1) Open collector, no pull up.</p> <p>(Hardware Version 2) Open collector, with removable pull up.</p> <p>This output is normally used to mute the local speaker during data transmissions. It goes active after the TRK-240 has determined that data is being received. Therefore a small amount of the data packet may be heard. This output is always active (until unit called) during Closed Mode operation. Connect this wire to a point that will mute the local speaker but not affect the receive audio pickup point. Some radios with accessory connectors provide an input for this.</p> <p>The active state of this output is programmable.</p>	Output
15	Power	7-16v	Power to external device	
16	Auxiliary in 1	-35 to 35v	<p>Z = 100K, -35V to +35V</p> <p>Used to sense external conditions or devices.</p>	Input
17	Auxiliary out 1	OC	<p>(Hardware Version 1) Open collector, no pull up.</p> <p>(Hardware Version 2) Open collector, with removable pull up.</p> <p>This output can function as a standard auxiliary output (activated by command from Dispatch) or can be used for Channel Steering. The active state of this output is programmable.</p> <p>Maximum Sink Current 300ma.</p>	Output
18	Net A TX Diag	RS485 RS232	<p>(Hardware Version 1) Serial in/out to peripheral devices</p> <p>(Hardware Version 2) Serial in/out to peripheral devices</p>	I/O I/O
19	Net B RX Diag	RS485 RS232	<p>(Hardware Version 1) Serial in/out to peripheral devices</p> <p>(Hardware Version 2) Serial in/out to peripheral devices</p>	I/O I/O
20	Ground			
21	Tx radio serial	TTL	Serial out to peripheral devices or data port of radio	Output
22	Rx radio serial	TTL	Serial out to peripheral devices or data port of radio	Input
23	RTS radio serial	TTL	Serial out to peripheral devices or data port of radio	Output
24	CTS radio serial	TTL	Serial out to peripheral devices or data port of radio	Input

25	Ground			
----	--------	--	--	--

CONNECTOR PIN ASSIGNMENTS

Pin	Function	Type	Notes	Direction
1	Power	8-16v	Power to external device	
2	Ground		Ground to external device	
3	Net A TX-Programming	RS485 RS232	(Hardware Version 1) Serial in/out to peripheral devices (Hardware Version 2) Serial in/out to Programmer	I/O I/O
4	Net B RX-Programming	RS485 RS232	(Hardware Version 1) Serial in/out to peripheral devices (Hardware Version 2) Serial in/out to Programmer	I/O I/O
5	Ground			
6	Auxiliary out 1	OC	(Hardware Version 1) Open collector, no pull up. (Hardware Version 2) Open collector, with removable pull up. Used to control external devices. The active state of this output is programmable. Maximum Sink Current 300ma.	Output
7	Auxiliary out 2	OC	(Hardware Version 1) Open collector, no pull up. (Hardware Version 2) Open collector, with removable pull up. Used to control external devices. The active state of this output is programmable. Maximum Sink Current 300ma.	Output
8	Auxiliary out 3	OC	(Hardware Version 1) Open collector, no pull up. (Hardware Version 2) Open collector, with removable pull up. Used to control external devices. The active state of this output is programmable. Maximum Sink Current 300ma.	Output
9	Auxiliary in 1	-35 to 35v	Z = 100K, -35V to +35V Used to sense external conditions, sensors or devices.	Input
10	Auxiliary in 2	-35 to 35v	Z = 100K, -35V to +35V Used to sense external conditions, sensors or devices.	Input
11	Auxiliary in 3	-35 to 35v	Z = 100K, -35V to +35V Used to sense external conditions, sensors or devices.	Input
12	Horn honk	Relay, C	Common relay contact, 4 Amp Max	Output
13	Horn honk	Relay, NO	Normally open relay contact, 4 Amp Max	Output
14	Emergency	0-5v	Logic input (when activated sends specific emergency packet) Connect through a switch to ground with an optional 1K resistor. <i>See Figure 1</i>	Input
15	Ignition	-35 to 35v	Z = 100K, -35V to +35V Connect this input to the vehicle ignition to inhibit the Horn Honk function while the ignition is active.	Input
16	Tx port 2	RS232	Serial out to peripheral devices or data port of radio	Output
17	Rx port 2	RS232	Serial out to peripheral devices or data port of radio	Input
18	RTS port 2	RS232	Serial out to peripheral devices or data port of radio	Output
19	CTS port 2	RS232	Serial out to peripheral devices or data port of radio	Input

20	Ground			
21	Tx port 3	TTL	Serial out to peripheral devices or data port of radio	Output
22	Rx port 3	TTL	Serial out to peripheral devices or data port of radio	Input
23	RTS port 3	TTL	Serial out to peripheral devices or data port of radio	Output
24	CTS port 3	TTL	Serial out to peripheral devices or data port of radio	Input
25	Ground			

Notes:

- OC stands for open collector
- All audio inputs and outputs are capacitor coupled
- Auxiliary outputs can sink 100ma. of current

Note: Adjustments are NOT necessary if interfacing the TRK-240 with a serial data port.

Observe normal static prevention practices. After programming the TRK-240 connect the radio interface harness to the radio and the terminal.

- A. Apply power to the radio and turn the power switch on.
- B. Set the service monitor to receive on the transmitter frequency. If the service monitor does not incorporate an oscilloscope, connect an external oscilloscope to the demodulation output.
- C. If the radio is being used on a conventional system, connect a RF dummy load to the radio. Go to step (E).
- D. If the radio is being used on an LTR or Smartnet system connect the radio to a suitable antenna.
- E. The model TRK-240 should operate properly as setup at the factory. However it will be necessary to adjust the data levels for optimum performance. A service monitor, oscilloscope, or a deviation meter will be needed to properly adjust levels.

RX Audio Hardware Version 1

Using a service monitor, generate a 1kHz signal at 4.0 kHz (Wide band), 2 kHz (Narrow Band) deviation on the receiver frequency and adjust R10 to achieve a level of 600 ~ 800 mvpp. at TP1. Alternately LED D1 can be used as an indication for accurate adjustment. Adjust R10 such that D1 is just beginning to illuminate while receiving the test tone. If this level cannot be reached or level is inadequate, add JP2 and re-adjust.

TX Audio Hardware Version 1

- 1. Set the service monitor to receive on the transmitter's frequency.
- 2. Enter Diagnostic mode (see section 6.0, Local Diagnostic Mode).
- 3. Enter 3 to select test outputs.
- 4. Enter 1 to select modem.
- 5. Enter 1, 2 or 3 to cause the TRK-240 to transmit a test tone.
- 6. While the radio is transmitting, adjust R15 inside the TRK-240 to obtain maximum system deviation without being limited.

NOTE: *The TRK-240 may not key the transmitter if it is not installed or programmed appropriately for the radio it is attached to. Refer to the appropriate CES radio application note for help.*

RX Audio Hardware Version 2

- 1. Using a service monitor, generate a 1kHz signal at 4.0 kHz (Wide Band), 2.0 kHz (Narrow Band) deviation on the receiver frequency.
- 2. Enter the local diagnostic mode (see section 6).
- 3. Enter 7 for levels
- 4. Press 4 as many times as necessary until RX Low indicates "Too Low"
- 5. Then press 3 as many times as necessary until RX High indicates "Too High". While doing this, count how many times the 3 was pushed. Then push 4 half as many times as 3.
- 6. Both RX high and RX low should indicate OK.

TX Audio Hardware Version 2

1. Set the service monitor to receive on the transmitter's frequency.
2. Enter Diagnostic mode (see section 6.0, Local Diagnostic Mode).
3. Enter 3 to select test outputs.
4. Enter 1 to select modem.
5. Enter 1, 2 or 3 to cause the TRK-240 to transmit a test tone.
6. While the radio is transmitting, press keys 4 or 5 to obtain maximum system deviation without being limited. Typically 4 Khz on wide band and 2 Khz on narrow band.

NOTE: The TRK-240 may not key the transmitter if it is not installed or programmed appropriately for the radio it is attached to. Refer to the appropriate CES radio application note for help.

3.0 Programming

Setting up the Computer

The *TRK-240* is programmed using an IBM-compatible computer, Microsoft Windows, together with the CES WIRELESS TRK-240S programming software and the *ARI-199P* or *TRK-240PA* hardware interface kit.

The personal computer must be:

- ◆ IBM-compatible
- ◆ Microsoft Windows
- ◆ Hard disk drive with 2.0 Megabyte free space
- ◆ 4 MB RAM memory
- ◆ An RS232 COM port with either a DB25 or DB9 type connector

Installing TRK-240S Software

Place CD Soft 1 into the CD ROM drive. From the Windows **Start Button** select **Run**. Select **Browse** and then the CD ROM drive.

Open the “Programming Software” folder and then the “TRK-240s” folder.

Then select and open the “setup.exe” file. This will run the Windows Installation Wizard and allow you to install the program to a folder of your choice. Otherwise the program will install to c:/program files/CES Wireless Technologies/TRK-240s.


During installation of the software the instructions may prompt you to close other applications. This prompt will be displayed whether you have other applications open or not. If you have other applications open you must close them before continuing. If you have no other applications open just proceed.

The TRK-240S software installation will place an icon on the desktop to start the program.

4.0 Software Operation


Connect the programming adapter (TRK-PGMR) to the PC and TRK-240 following the diagram below. The programming kit is supplied with adapter cables for all CES data products. Make sure to use adapter cable (08001240) otherwise damage may occur.

The original programming adapter is called the TRK-240PA. This adapter connects directly to the 240 and then to the computer via a DB25 Male to DB9 Female cable.



TRK-240S Flow Chart

TRK-240 Programming Software Flow Chart



The Blue boxes represent organizational and housekeeping functions.

Yellow represents main menu selections for TRK-240 programming.

Green represent selections as a result of selecting TRK-240 System Parameters



Initialize Software

Run the *TRK-240S program* by double clicking on the TRK-240S icon on your desktop. Once started this menu will ask for the TRK-240 “firmware” version you wish to use during this session.

Firmware is the unique code developed by CES Wireless to provide the TRK-240 with its feature set and compatibility with various wireless networks. This is continuously enhanced, and in most instances is backward compatible. However, it is very important that the TRK-240 is programmed with the correct firmware version set in the programming software.

If you do not know what version of firmware is loaded in the TRK-240, you can read the firmware version on power up of the TRK-240, (monetarily displayed on the TRK-240 screen) or you can click on “ok” or press “enter” and go to the “Program” menu. Select “Get Product ID” to read it.

NOTE: If you get a warning message that the “Mobile is NOT responding” go to the “Configure” and verify that the correct serial port is selected. If so, refer to section 3 to verify that the correct programming interface and configuration is being used.



This information box will display the firmware version of the TRK-240.

You must then shut down and restart the program and then select the appropriate version to continue.

Now, using the drop down menu select the appropriate version to proceed and click on the “ok” button or hit “enter”.

After initialization the following screen (or similar) will then appear.

Actual view may vary due to programs backward compatibility dependent on the firmware version.

Lets first take a look at the screen layout. From the top of the screen you can select from a row of drop down menus, e.g. **File, Device, Configure, Program, Diagnostics and Help**. This menu always remains on the screen.

Selecting **Device** provide access to different operational aspects of the TRK-240 programming. All of the other selections, File, Configure, Program, Diagnostics and Help provide the capability to do routine organization and programming tasks.

Device provides five programming selections:

- Set TRK-240 to Default Settings**
- Set TRK-240 System Parameters**
- Set TRK-240 Predefined Messages**
- Set TRK-240 geo-STATUS™**
- Set TRK-240 Legends/Sub Menus**
- Set TRK-240 Auxiliary Inputs**

NOTE: A Configuration file must be created for each of these selections used except “Set TRK-240 to Default Settings”

Because we are continuously updating and enhancing this product, we have made the TRK-240S backward compatible. This means that you can program older versions of the TRK-240 terminal with newer versions of the programming software.

Lets go back to the **main menu** and examine the drop down menu items first.

FILE

Open

Open an existing customer configuration or predefined message file previously saved to disk.


Save

Save the existing customer configuration or predefined messages file.

***NOTE:** When you save a TRK-240 configuration file, it would be wise to imbed the firmware version and customer initials into the file name.*

Save As

Save a configuration file.



Edit Comment Field

Enter a comment, e.g. customers name that will be appended to the existing file when saved. This comment is included when the file is printed.

Print

Print the displayed file. This is particularly useful to commit a written record of the customers programmed parameters to paper files, or to fax to CES WIRELESS in the event you require assistance.

Exit

Select this to exit the TRK-240S software

DEVICE

There are many aspects to programming the TRK-240. Rather than lumping all of them together, some aspects have been kept separate, and accessible via the “Device” drop down menu. Because of this, a separate configuration file is created for each of the device selection available, (except Set to Defaults).

In other words, If all 5 device types will be utilized, 5 configuration files will be created and should be saved. The software appends a different extension to each device type file name.

Set to Defaults

Selecting this will set all programming fields to factory default settings.

System Parameters

The System Parameters are displayed when the program is first opened, or when selected from the Device menu. The System Parameters define the basic operation of the TRK-240. The other device selections are optional.

TRK-240 Predefined Messages (Outbound)

The TRK-240 can be programmed with up to 50 (4 lines x 40 characters) “Predefined” (or sometimes referred to as Canned) messages. The dispatch center can command these messages to appear on the TRK-240 terminal. These would be used for messages sent routinely that typically would not change. Using canned messages also saves air time.

TRK-240 geo-STATUS™

Up to 30 geo-STATUS™ can be programmed into the TRK-240. A geo-STATUS™ is a geographic region that is recognized by the TRK-240 and acted upon. The TRK-240 can be programmed to report on entry and/or exit of this region. Its upper left and lower right geographic coordinates define the box.

TRK-240 Legends/Sub Menus

The TRK-240 can also be programmed with the ability to display key driven sub-menus. These sub menus could be used for 2 purposes. 1, to prompt the driver for additional numeric entries such as Enter Starting Mileage, Enter Job Number etc. or 2, as a drop down list of text messages that the driver can select from to cause a message to be displayed by Quick-trak.

Auxiliary Inputs

The TRK-240 has 4 Auxiliary inputs. These inputs are typically used to sense events in the vehicle. Such as, Ignition On / Off, Door Open / Closed, and so on. These inputs trigger on a High verses Low signal, and can be programmed to trigger upon 3 conditions. High to Low transition, Low to High transition, or both. The auxiliary inputs *cannot* detect any conditions other than on or off, such as fluid levels or temperatures.

A more detailed explanation of the device type selections and programming fields can be found in section 5 of this document.



Configure


Com Port

Change above to "Select the Serial Communications Port (1-8) that the TRK-240 is connected to.

If the Communications Port selected is not valid for this computer, the message "Com Port not available" will be displayed. Once selected, the COM port configuration will be saved for future programming sessions.

Verify Mobile Connection

Select this to verify that the software is communicating with the TRK-240 terminal.



PROGRAM

Set Unit to factory Defaults

Returns the TRK-240 to factory default settings.

Warning, This will restore all device type settings

Get Unit Configuration

Select this item to download (read) the current TRK-240 programming.

Send Unit Configuration

Select this item to program the TRK-240. This command will update the TRK-240 with any changes that have been made or configuration file that is open.

Compare Unit Configuration

Select this item to compare the TRK-240 parameters to that displayed by the TRK240S parameter fields.

Get Serial Number


Select this item to read the Serial Number of the TRK-240. This serial number is coded and is for CES internal use only.

Get Product ID

Select this to obtain the factory-preset Product ID Code and firmware version. This may be required by CES WIRELESS for support purposes.

Begin Sequential Programming

Select this if you are programming a number of TRK-240 terminals identically except with sequential unit ID numbers. The program will automatically increment the unit ID by one each time you program a unit.




Configure CDPD Radio

Although this area of the software is still available, CDPD service is no longer available. Because of this, the explanations of these fields have been deleted from this document.

Help

About

This message box will give you the software version and copyright information.



5.0 TRK-240 System Parameters

The parameters for the TRK-240 are entered using the “tabs” on the main screen.

Before changing any parameter, make sure you understand the significance of the parameter, and what the change will do to the operation of the TRK-240. If this is a new system, understand the overall system concept before proceeding, and remember, always maintain compatibility with the base configuration. If this is an existing system, you can open a previously saved config (.cfg) file by going to *File, Open*.

You can also read the current TRK-240 program values by going to *Program, Get Unit Configuration*.

RADIO

The screenshot shows the 'Radio' configuration window for the TRK-240S. The window has a menu bar with 'File', 'Device', 'Configure', 'Program', 'Diagnostics', and 'Help'. Below the menu bar is a tabbed interface with tabs for 'Radio', 'Channel Change', 'I/O', 'Serial', 'GPS', 'ANI / Status', 'Key 1,2', 'Key 3,4', 'Key 5,6', 'Key 7,8', 'Key 9,0', and 'Key *,#'. The 'Radio' tab is active, displaying several configuration sections:

- Unit ID:** System ID: 0, Unit ID: 1
- Group ID's:** Group 1: 0, Group 2: 0, Group 3: 0, Group 4: 0, Group 5: 0, Group 6: 0, Group 7: 0, Group 8: 0, Group 9: 0, Group 10: 0
- Radio Interface:** Baud Rate: 1200, Radio Type: Conventional, Lead In Delay: 50 x 10ms, Request Check: 50 x 1ms, Request Window: 100 x 10ms, Grant Check: 20 x 10ms, Grant Window: 300 x 10ms
- Encryption:** Encrypt 1: 0, Encrypt 2: 0, Encrypt 3: 0
- Busy:** ☒ Ignore When Sending Acks, ☒ Ignore When PTT In Is Active, Frame Transmit Function: Before and After Channel Change, Holdoff Time: 200 x 10ms, ☐ Busy must be active to receive frames
- Frame Transmit:** Ack Wait Time: 500 x 10ms, Retry Window: 500 x 10ms, Repeat Count: 4, Ack Response Time: 10 x 10ms

Actual view may vary due to programs backward compatibility dependent on the firmware version.

System ID

Programmable from 0-63, default is 0. Used as a unique identifier in cases where multiple companies access the same radio frequency. This keeps Tim's Taxi from viewing the data from Tom's Towing.

Unit ID

This is the address of the mobile unit when operating on conventional and trunked radio systems. A unique Unit ID is required for each mobile within the fleet. Valid Ids range from 00001-32767 whereas 32767 will be the maximum number allowed.

Note: The factory default address is 00001.

Group ID

Up to 10-group call ID's can be programmed on conventional and trunked radio systems. An ID of 0 disables the entry. Programmable from 1-32767. Default is 0.

Radio Interface

Baud Rate

This specifies the modem baud rate. Programmable for 600, 1200, 2400, 3840 or 4800 bps. The baud rate selected must be consistent throughout the fleet and must be capable of operating reliably on the selected radio system. For example, most repeater systems are not capable of handling anything greater than 2400 baud.

Radio Type

Selects the type of radio system (conventional, trunking etc.,) that the unit will be operating in. Some radio types are firmware dependent. At this time, use LTR for all trunking applications. Otherwise refer to an appropriate CES application note for instructions.

Note:

Selecting the firmware in the mobile will determine which menu items will be shown in the drop down menu list.

Selections	Explanation
	Firmware Version xx.05.44 or less
<No Busy>	The <i>TRK-240</i> will ignore the radio busy signal condition if No Busy is selected. (Not appropriate for most applications)
<Use Busy>	If the <i>TRK-240</i> Busy input is connected to the radio, the <i>TRK-240</i> will not transmit when the radio channel is busy. (Appropriate setting for Conventional applications)

Selections	Explanation
	Firmware Version xx.05.44 or higher
<None>	This item is reserved for future use and is not a valid selection.
<Conventional>	If the <i>TRK-240</i> Busy input is connected to the radio, the <i>TRK-240</i> will not transmit when the radio channel is busy.
<LTR> or <Smartnet>	The <i>TRK-240</i> is LTR™ and Smartnet™ trunking compatible. Interfacing to a trunking radio is more complex than interfacing to a conventional radio, since the <i>TRK-240</i> must first request a channel from the network before transmitting status information. This communication period can take hundreds of milliseconds and may result in denial of channel access. If interfacing to a Trunking radio, make sure that the <i>TRK-240</i> Trunk/Busy Detect input is connected to a suitable point on the radio, Clear to Send (Motorola), Link Complete (Kenwood) or TX Volts.
<IDEN-Packet>	Not implemented at this time.
<CDPD-MP200>	The <i>TRK-240</i> is compatible with CDPD and can be easily interfaced to selected CDPD transceivers. The MP-200 is a Sierra Wireless Transceiver.
<CDPD-D1000>	The D1000 is a Uniden CDPD transceiver
<CDPD-NRM6832>	This is the Expedite CDPD transceiver from Novatel Wireless
<CDPD-TPRM-130C>	This CDPD transceiver is from Tellus Technologies.
<GSM-SMS-GM22>	This is for interface to the GSM network using the SMS feature. This selection uses the Ericsson GM-22 transceiver. Not operational at this time.
<GSM-SMS> <Redhawk>	This GSM transceiver is the Redhawk from Xircom. It uses the SMS feature.
<MSAT-PDT100>	The <i>TRK-240</i> has been interfaced to the MSAT satellite network using the PDT-100 from TMI Communications.
<MSAT-MDT1000>	This MSAT transceiver is from Narrowband Telecommunications.
<GPRS-CVM-2317>	This is a GPRS transceiver from Wanecom
<CDMA-AnyData <EMIII>	This is a CDMA transceiver from AnyData
<GPRS-Enfora> <Spider>	This is a GPRS transceiver from Enfora

Note: Units that have integral CDPD, CDMA or GPRS transceivers will be programmed with the appropriate setting from the factory.

Lead In delay

This is the period of time that the TRK-240 will cause the radio or transmitter to key prior to encoding the ANI or status information. This is necessary to give repeaters, line equipment or base stations sufficient time to settle prior to reception of the signal information. Programmable from 0-200 in 10ms increments. Default is 10 (=100ms).

The following parameters are used to define trunking operation. When the TRK-240 wants to transmit, it will activate the PTT output. It then monitors activity on the Trunk/Busy detect input to see if the radio gained access to the system. The programming parameters used to accomplish this are as follows. The factory default settings should be sufficient for most LTR or Smartnet systems. However, you can optimize the system by changing the following.

Busy/Request Check or Request Check

When the push to talk output goes active to access the radio system, the TRK-240 monitors the Channel Available input for activity (the channel available input is connected to the radios tx volt line or link complete output). This line goes active when the radio is granted a channel or makes a channel request. The Request Check slider sets the minimum time in which the TRK-240 will consider that the radio has made a valid request. In other words, the Channel Available input must be active for at least the time set by this slider, or the TRK-240 will consider that the radio has not made a request. Programmable from 1-2000 in increments of 1ms. Default is 50 (=50ms).

Request Window

This is the length of time that the TRK-240 monitors the channel available input looking for the radio to make a channel request. Note that the request must fall entirely within this window.

Programmable from 1-200 in 10ms increments. Default is 50 (=500ms).

Grant Check

During the course of the Grant Window the radio may make several channel requests. This timer is to discriminate between a channel request and a channel grant. Only when the channel has been granted, will the data be sent.

When the trunking system grants the radio a channel, the next transmission will be longer than a request check. The TRK-240 monitors the channel available input looking for request checks or a channel grant. When the channel available input is active for the period set in the Grant Check timer the TRK-240 assumes the channel has been granted. Therefore the Grant Check value must be longer than the Request Check value. Programmable from 1-200 in 10ms increments. Default is 20 (=200ms).

Grant Window

This is the length of time that the TRK-240 monitors the Channel Available input looking for a Channel Grant. Note that the Channel Grant must fall entirely within this window. This timer would typically be set to 3 or 4 seconds, just under the time that the radios error tone starts when no channel has been granted. Programmable from 1-10000 in 10ms increments. Default is 200 (=2000ms).

Typical settings	LTR sensing TX volts	Smartnet sensing TX volts	Either sensing Clear to send / Link Complete
Request Check	50ms.	20ms.	10ms.
Request Window	1 sec.	500ms.	3.5 sec
Grant Check	200ms.	100ms.	20ms.
Grant Window	3.5 sec.	3.5sec.	4.0sec.

Note: These settings are typical, however some radios differ slightly from this.

Encryption

To prevent unauthorized decoding of the data, a 3 level encryption technique is employed when using conventional or trunking radio systems. . Valid ranges are 0-65535. Default is 0.

Busy

Ignore Busy when Sending Acks

The TRK-240 will not monitor the radio busy channel when sending acknowledgments if this is enabled. If the TRK-240 is operating through a conventional repeater system with Hang Time, this parameter should be enabled.

Ignore Busy when PTT is Active

If the TRK-240 operates on a repeater system with a Hang Time, this parameter would be enabled. The TRK-240 will not monitor the radios busy channel indicator when PTT in (local microphone) goes active.

Frame Transmit Function

The busy input may be checked before and / or after the channel is changed. Use this parameter to select when busy is to be sampled. If set to off, busy input is ignored.

Selections	Explanation
Off	Selecting off causes TRK-240 to ignore the busy input when sending frames. This setting should only be used for testing purposes.
Before Channel Change	Causes unit to check voice channel busy condition, then change channels and send data regardless of data channel condition.
After Channel Change	Causes unit to ignore voice channel busy condition, change channels, then check busy prior to sending data.
Before and After Channel Change	Causes unit to check voice channel busy condition, change channels, and check busy condition again prior to sending data. <i>(This is the typical setting)</i>

Holdoff Time

The amount of time the busy input must be inactive before the TRK-240 considers the channel is available. This timer would normally be set to a several seconds, assuming the radio is used for both voice and data. *Programmable from 1 - 65535 in 10ms increments, Default is 1 second.*

Busy must be active to receive frames.

When enabled, data received while the radio's COS / Busy output is not active will be ignored. This should be enabled when the following 3 conditions exist.

1. The radio system is LTR
2. The radio is being steered to a specific group to send data.
3. The receive audio source to the TRK-240 is un-squelched

Frame Transmit

Ack Wait Time

When the TRK-240 sends a transmission to the base Controller, it waits for an acknowledgment. This time defines how long to wait before considering the send a failure and initiating a retry. Programmable from 100 - 12000 in 10ms increments. Default is 200 (=2000ms).

Retry Window

When the TRK-240 sends a packet that must be acknowledged, it first waits the value of the "Ack Wait Time". If this time expires without an ack being received, it then waits an additional period of time before sending a retry. This additional time is derived randomly from the "Retry Time Window" value. The purpose of this is to insure that, if the initial sends from 2 or more mobile devices collide, the random value pulled from this timer will insure that the retries do not collide. This entry defines the upper limit of how long the random time can be. Programmable from 10 - 12000 in 10ms increments. Default is 500 (=5000ms).

Repeat Count

Defines the number of times to re-send a transmission and wait for an acknowledge before giving up. Programmable from 1-1000. Default is 4.

Ack Response Time

This is the amount of time to wait after receiving a packet before sending the acknowledgment. This time should be as short as possible yet maintaining reliability.

Channel Change

This tab and settings apply only to radio types 'Conventional', 'LTR' and 'Smartnet'.

The settings shown below are typical for radios that have a data mode

Actual view may vary due to programs backward compatibility dependent on the firmware version.

Channel Change – Before Data is Sent

Selections	Explanation
Off	No channel change
Activate aux out R	Activates the auxiliary output R wire prior to sending data.
Pulse aux out R	Pulses the auxiliary out R wire prior to sending data.
Standard GX4800UT (Sys1, Grp 1)	(See Note 1 below)

NOTE: This selection is a channel change type specific to the Standard GX4800UT radio. When this is selected, all data transmissions will occur on group 1 of system 1. This will not accommodate sending data on more than one trunked site.

Timer 1

This is a generic timer setting that has different functions for each channel change type.. When the Channel Change type selected is set to *Activate*, this timer has no function. When the Channel Change type selected is set to *Pulse*, this timer sets the duty cycle of the pulse / pulses.

Timer 2

This is a generic timer setting that has different functions for each channel change type. When the Channel Change type selected is set to *Activate*, this timer determines the time between the activation and Push to Talk occurring. When the Channel Change type selected is set to *Pulse*, this timer sets a wait time between the pulse / pulses and checking busy channel condition prior to sending data.

Count

Determines the number of pulses when the channel change type is set for pulse.

Change

Selections	Explanation
Before channel is accessed	The channel change action occurs before the PTT is activated. (<i>Typical Setting</i>)
After channel is accessed	The channel change action occurs after the PTT is activated.

Channel Change – After Data is Sent

Selections	Explanation
Off	No Channel Change after data is sent.
Deactivate Aux out R	Deactivates Aux out R pin after data is sent
Pulse Aux out 1	Pulse Aux out R, send frame, pulse Aux out 1 a programmable number of times (See Note 1)

Timer 1

This is a generic timer setting that has different functions for each channel change type. When the Channel Change type selected is set to *Deactivate*, this timer has no function. When the Channel Change type selected is set to *Pulse*, this timer sets the duty cycle of the pulse / pulses.

Timer 2

When the Channel Change type selected is set to *Deactivate*, this timer determines the time between the receipt of the acknowledgement and the deactivation of the output. When the Channel Change type selected is set to *Pulse*, this timer sets the time between the receipt of the acknowledgement and the pulse / pulses.

Count

Determines the number of pulses when the channel change type is set for pulse.

Change

Selections	Explanation
When frame is sent	Changes channel (back to voice channel) after the data is sent
When Ack is received	Changes channel (back to voice channel) after the acknowledgement is received

Release PTT After Channel Change for Acks

Select if PTT is to be released after the channel change when sending acknowledgments. This function when enabled causes the Aux out R to go inactive after Push to Talk inactive during acknowledgements only. This is for use with Kenwood radios when channel steering to a data group is used.

Acknowledgements

Perform channel change

Causes the channel change action when sending acknowledgements. If outbound transmissions (base initiated) are sent on the voice channel, then this should not be enabled.

Decrement retries on channel access error.

With this enabled, “retries” will be exhausted when channel access failures occur in trunked operation. With this disabled, the TRK-240 will attempt channel access indefinitely until a channel is granted.

Enable Strip Turn Off Code on Aux out 1

This output provides the ability to determine whether repeater “turn off code” is sent upon release of push to talk in a trunked system. This allows acknowledgements to be transmitted on the still active repeater without the radio doing a channel request. Utilizing this function will increase the data throughput of a trunked system.

NOTE 1: This functionality is radio specific and currently only works with the Motorola CDM1550LS+ and the Motorola M1225 with Scholer Johnson option board.

PASSPORT - Registration Input (Aux In 1)

This input provides an indication to the TRK-240 as to whether or not the radio is registered for Passport trunking operation.

This input (when inactive) signals the TRK-240 that the radio is not registered therefore it will not attempt to transmit data.

NOTE: This functionality is radio specific and only works with Passport radios that provide such an output.

I/O (Inputs & Outputs)

To set up the Auxiliary inputs, select Device, and Auxiliary Inputs.

This tab contains the fields that determine the direction of the outputs when in the active state. This tab also contains the fields that determine what is considered the active state of signals coming from the radio, such as the busy input.

The programming of the Auxiliary Inputs has been relocated to the Auxiliary Inputs Device Type. The new device type can be selected by selecting the Device pull down menu and clicking on Auxiliary Inputs or you can click on the button below.

Note: changing device types resets all parameters so be sure to save the current settings before switching device types.

Auxiliary Inputs Device Type

Talk Mode
Mode: Open Alert Time: 1000 x 10ms Reset Time: 1000 x 10ms Initial State: Open

Horn
☐ Enable On Count: 3 On Time: 100 x 10ms Off Time: 100 x 10ms

Speaker Mute
Active During: ☐ Ack Wait Time ☐ Frame Transmit
☐ Enable Constant Speaker Mute
Auto-mute Duration: 20 x 10ms

Output Polarity
Aux Out 1: Active lo (invert) Mic Mute: Active lo Speaker Mute: Active lo
Aux Out 2: Active lo (invert) PTT: Active lo Horn Honk: Active lo
Aux Out 3: Active lo (invert) Speaker Enable: Active lo Aux Out R: Active lo

Input Polarity
Trunk: Active lo Ignition: Active lo
PTT: Active lo Busy: Active lo

Emergency
Input: Off Supervisory: Off

Actual view may vary due to programs backward compatibility dependent on the firmware version.

Output Polarity

Aux Out 1-3

Selections	Explanation
Active hi	When activated by a command from Base this output goes High (to the supply voltage) via a 27k ohm pull-up resistor.
Active lo (invert)	When activated by a command from Base this output goes Low via an N channel FET.

Mic Mute

This selection determines the active state of the mic mute output. This output is used to mute the local microphone when ANI (PTT ID) is sent. If Leading or Random ANI will be used, this output should be connected. Otherwise this output is not required. Select the active state that is appropriate for the radio being used. (Normally active low)

PTT

This selection determines the active state of the Push to Talk output. Select the active state that is appropriate for the radio being used. (Normally active low)

Speaker Enable

The TRK-240 comes standard with an enunciator that provides audible feedback to various actions and conditions. Alternately the TRK-240 has a tone output that if wired into the radios audio amplifier circuitry can provide this feedback through the radios local speaker. This output is used on radio models that require a signal to turn on the audio amplifier. . Select the active state that is appropriate for the radio being used.

Speaker Mute

This selection determines the active state of the speaker mute output. The speaker mute function is always active. Only the appropriate state need be selected. Select the active state that is appropriate for the radio being used.

Horn Honk

This selection determines the active state of the horn honk relay (normally open or normally closed). Select the active state that fits your requirement.

Aux Out R

This selection determines the active state of the Auxiliary output R wire. This output is used for Channel Change. Select the active state that is appropriate for the application.

Speaker Mute Active During

Ack Wait time

When enabled, the TRK-240 will mute the radios speaker during the acknowledgement wait time.

Frame transmit

When enabled, the TRK-240 will mute the radios speaker during data transmissions. This function is provided specifically to eliminate talk permit and out of range beeps generated by the radio in trunked operation.

Enable Constant Speaker Mute & Auto Mute Duration

When enabled, the TRK-240 speaker mute output will always be active whenever the radios carrier/talkgroup detect output is inactive. The speaker mute output will un-mute when the radios carrier/talkgroup detect becomes active and the Auto Mute Duration value expires. The purpose for this is to mute the first 100 to 200ms. of a transmission in order to determine whether it is a data or voice transmission. If during the Auto Mute Duration, data is detected, the speaker mute output will not un-mute. This value should be kept as short as possible, as too long of value will effect voice transmissions. To keep this value short, it is essential to minimize the Lead in Delay of the MDC-150 (base end radio modem).

Talk Mode

Alert Time

This selection sets the maximum amount of time the TRK-240s enunciator will beep when a call is received. A setting of 0 will cause the unit to beep indefinitely. The beeping will stop if a key is pushed or PTT activated. Programmable from 0-50000 in 10ms increments. 0 = infinity. Default is 1000 (=10000ms).

Mode

This setting determines the talk mode of the TRK-240, Open or Closed. The Open mode allows the radio to be used normally (allowing radio use at any time). This is the preferred mode of operation. The Closed mode, only allows the radio to be used (both transmit and receive) upon requests from drivers and or commands from the dispatcher.

Note: Closed mode generally requires radio modifications.

Reset Time

This setting determines how long the TRK-240 will remain in the Open mode. After being called and microphone activity has stopped. This setting only applies to units operating in the closed mode. Programmable from 10-50000 in 10ms increments. Default is 1000 (=10000ms).

Initial State

This setting determines the talk mode condition upon radio power-up. This setting only applies to units operating in the closed mode.

Horn

Enable or Disable

Enable or disable the Horn Alert feature. (The ignition input should be used if the Horn Honk feature will be enabled.

On Count

This setting determines the maximum number of times the horn will honk (if enabled) when called. The horn will automatically shut off if "PTT in" is activated or a key is pressed. Programmable from 1-25. Default is 3.

On Time

This selection sets the time the horn is on in the sequence. Programmable from 10-1000 in 10ms increments. Default is 100 (=1000ms).

Off Time

This selection sets the time the horn is off in the sequence. Programmable from 10-1000 in 10ms increments. Default is 100 (=1000ms).

Input Polarity

Trunk

Used in LTR or Smartnet mode only. This input is typically connected to TX volts to sense when the radio is transmitting. This selection determines the active state of the Trunk input. Select the active state that is appropriate for the radio being used.

PTT

This selection determines the active state of the Push to Talk input. Select the active state that is appropriate for the radio being used. (Normally low)

Ignition

This selection determines the active state of the Ignition input. Select the active state that is appropriate for the application. (Normally high) An external pull down resistor may be required. This input serves two purposes. 1. To disable the Horn Honk feature when active. 2. Can be set up to send an ignition active packet.

Busy

This selection determines the active state of the Busy input. Select the active state that is appropriate for the radio being used.

Emergency


Input

This selection enables the Emergency input and determines when to send the emergency signal based on the input condition. Selections are OFF, send on switch closed, switch opened or both.

Supervisory

This selection enables the Emergency Supervisory mode and determines the condition required to activate it. Selections are, off, send on wire cut, and send on wire connected or both. See TRK-240 user manual for explanation of supervisory mode.

A detailed description for setting up the Emergency and Auxiliary inputs can be found in CES product bulletin PB1526.



Serial

The following screen provides the capability to program parameters relating to the interface of a serial devices including transceivers using a serial data ready radio, magnetic card reader, serial printer or the CES GPS Automatic Vehicle Location option. Only CES compatible devices can be used. If you have a device, firmware can be developed to make it compatible, subject to review. Contact CES Wireless for further details.

The screenshot shows the 'TRK-240S - [TRK-240]' configuration window. The 'Serial' tab is selected in the top menu. The interface includes several sections: 'Notes' with port pin and voltage level information; 'Serial Port Assignments' with dropdowns for Port 1, 2, and 3, and a list of available devices; 'Flash Box' settings for report time and auxiliary inputs; 'CDPD/GPRS/CDMA' settings for IP address, port, and modes; 'GSM' settings for base ID and service center; and a 'Printer' section with auto-eject, type, font size, and copies settings. A 'Header' section allows for adding, replacing, or deleting header information.

Actual view may vary due to programs backward compatibility dependent on the firmware version.

Serial Port Assignment

The TRK-240 has 3 serial ports. The available selections are the same for all ports. However specific CES peripherals are wired for specific ports. Below is a table indicating what settings are appropriate.

Peripheral Device	Port Selection & Setting	Peripheral Device	Port Selection & Setting
IDEN Packet	(Port) Radio Interface	GPRS CVM - 2317	(Port 3) Radio Interface
CDPD MP200	(Port 2) Radio Interface	CDMA AnyData EMIII	(Port 2) Radio Interface
CDPD D1000	(Port 2) Radio Interface	GPRS Enfora Spider	(Port 2) Radio Interface
CDPD NRM6832	(Port 3) Radio Interface	CRD-500	(Port 3) Card Reader
CDPD TPRM130C	No longer Supported	PRN-97	(Port 2) Printer
GSM GM22	(Port) Radio Interface	KBD-98	(Port 3) Keyboard
GSM Redhawk	No longer Supported	Flash Box	(Port 2) Flash Box
MSAT PDT100	No longer Supported	SLIP Interface	(Port 2) SLIP Interface
MSAT MDT1000	No longer Supported	Symbol P302FZY	(Port 2) Bar Code Reader

Wiring Pin-out for Serial Ports (Hardware version 1)

Pin	Function	Type		Direction
<i>Radio Cable</i>				
3	Net A	RS485	Polarity Sensitive. Connects to other peripheral devices.	I/O
4	Net B	RS485	Polarity Sensitive. Connects to other peripheral devices	I/O
5	Ground			
<i>Auxiliary Cable</i>				
16	Tx port 2	RS232	Serial out to peripheral devices or data port of radio	Output
17	Rx port 2	RS232	Serial in to peripheral devices or data port of radio	Input
18	RTS port 2	RS232	Serial out to peripheral devices or data port of radio	Output
19	CTS port 2	RS232	Serial in to peripheral devices or data port of radio	Input
20	Ground			
21	Tx port 3	TTL	Serial out to peripheral devices or data port of radio	Output
22	Rx port 3	TTL	Serial in to peripheral devices or data port of radio	Input
23	RTS port 3	TTL	Serial out to peripheral devices or data port of radio	Output
24	CTS port 3	TTL	Serial in to peripheral devices or data port of radio	Input
25	Ground			

Wiring Pin-out for Serial Ports (Hardware version 2)

Pin	Function	Type		Direction
<i>Radio Cable</i>				
21	Tx Port 1	RS232	Serial out to peripheral devices or data port of radio	Output
22	Rx Port 2	RS232	Serial in to peripheral devices or data port of radio	Input
23	RTS Port 1	RS232	Serial out to peripheral devices or data port of radio	Output
24	CTS Port 1	RS232	Serial in to peripheral devices or data port of radio	Input
25	Ground			
<i>Auxiliary Cable</i>				
16	Tx port 2	RS232	Serial out to peripheral devices or data port of radio	Output
17	Rx port 2	RS232	Serial in to peripheral devices or data port of radio	Input
18	RTS port 2	RS232	Serial out to peripheral devices or data port of radio	Output
19	CTS port 2	RS232	Serial in to peripheral devices or data port of radio	Input
20	Ground			
21	Tx port 3	TTL	Serial out to peripheral devices or data port of radio	Output
22	Rx port 3	TTL	Serial in to peripheral devices or data port of radio	Input
23	RTS port 3	TTL	Serial out to peripheral devices or data port of radio	Output
24	CTS port 3	TTL	Serial in to peripheral devices or data port of radio	Input
25	Ground			

Credit Card Operation

The TRK-240 supports the CRD-500 CES WIRELESS credit card reader.

To activate the reader, select the TRK-240 serial port that the reader is interfaced to.

To activate the credit card reader operation, set serial port 3 to Card reader.

Printer

The TRK-240 supports the PRN-97 CES WIRELESS mobile printer.

To activate the printer, select the TRK-240 serial port that the printer is interfaced to.

The PRN-97 prints messages of 160 characters during each print session. The dispatcher can of course send multiple messages each consisting of 160 characters. To activate the printer operation, set serial port 3 to Printer.

QWERTY Keyboard

The TRK-240 supports the KBD-98 CES WIRELESS QWERTY keyboard, providing the user with a capability to enter free from text messages onto the display screen and have them transmitted to the base dispatch. To activate the keyboard operation, set serial port 3 to Keyboard.

Bar Code Reader

The TRK-240 supports the Symbol (P302FZY) Bar code reader. Bar codes can be scanned and sent to the host software for processing. The host software would be 3rd party software developed for a specific application.

CDPD

Base ID

To program the terminal for CDPD operation, simply select the TRK-240 serial port, and then enter the Base ID Address (IP address of the base modem). In addition, make sure that the “radio type” selected under tab RADIO is CDPD. All of the product features are supported in the CDPD mode.

Remember only CES WIRELESS supported devices can be used. If you have an unsupported device, firmware can be completed to make it compatible. Contact CES WIRELESS for further details.

Printer

Auto Eject

Check *auto eject* if you want a number of blank lines automatically inserted after the message is printed.

This enables the driver to remove the paper slip cleanly without tearing the printer paper area.

Do not check *auto eject* if you intend to send multiple messages, were each message of 160 characters is associated with the previous one. The driver can activate the eject button on the printer to remove the paper slip cleanly without tearing the printer paper area.

Type

This selection sets the appropriate printer driver. The current selections are Generic & Pulsar.

Font Size

This selection sets the printer font size, small medium & large.

Copies

This selection determines how many copies to print. Up to 5 copies can be printed.

Header

This selection allows you to enter a header, and arrange how the printout will look.

Flash box

Intentional left blank.

CDPD/GPRS/CDMA

Base IP Address

Used for most radio types that use the cellular network for the data transfer. Sets the target IP address that the TRK-240 sends to. This is the fixed IP where the target server (mapping computer) resides.

UDP / TCP Port Setting

The TRK-240 uses UDP packets to communicate over CDPD and TCP packets over GPRS and CDMA. For CDPD operation, set this to 2100, 2200 for GPRS and 2300 for CDMA. *Default is 2100.*

CDPD Only

CDPD Open Mode

When enabled, the TRK-240 will change the base IP address when a valid packet is received from another address besides the programmed base ID. At power up, the address programmed in base ID is used.

GPRS/CDMA Only

APN

The APN (Access Point Name) is generally required for GPRS operation. This information is provided by the Service Provider, such as Cingular or T Mobile.

User Name

The User Name is generally required for CDMA operation. This information is provided by the Service Provider, such as Verizon or Alltel.

Password

The Password is generally required for CDMA operation. This information is provided by the Service Provider, such as Verizon or Alltel.

GSM

Base ID

Used for radio types GSM-SMS-Redhawk, GSM-SMS-GM22 and MSAT-PDT100. Sets the address the TRK-240 sends frames to. Although this field is available, it is no longer supported.

Service Center

Used for radio types GSM-SMS-Redhawk and GSM-SMS-GM22. Sets the service center number. Although this field is available, it is no longer supported.

GPS

Actual view may vary due to programs backward compatibility dependent on the firmware version

Basic GPS Functions

Enabled

To activate the GPS check this box to enabled GPS or uncheck it to disable the GPS option.

Message Generation Type

Select the message generation type. You have a choice of Timed, Event (MOTION-trak) or Compressed.

Timed: Sends the position information based on a programmable time parameter (0-10000 minutes) set below.

MOTION-trak: Sends position based on events

Compressed: Logs position, movement and speed and sends the data using a compressed technique on a programmable time parameter (0-10000 minutes)

NMEA Timed Position Sends

If the GPS module is a NMEA module (all but the Trimble SV6-CM3 are), packets can be sent without requiring acks, or they may be sent in the long-term queue, or sent normally requiring acks.

Selections	Explanation
Without acks	This option when selected does not require an acknowledgement from the base upon sending a position report. The position report will occur only one time (without retries) and if not received will be discarded.
With acks	This option when selected requires the base to acknowledge the position report. However, if the mobile is out of range and exhausts it's retries the position report will be discarded.
With acks & Long term Q	This option when selected requires the base to acknowledge the position report. If no acknowledgement is received after exhausting the retries, the report will go into long-term queue (be saved) to be sent again after the long-term queue "Procedure Time" is exhausted. All position reports will be stored until base acknowledgments can be received.

Communication Format

The Communication Format is determined by the actual GPS receiver installed in the unit. From the factory, the TRK-240 will be programmed for the receiver installed at the time of manufacture. The GPS functionality will not work if the unit is reprogrammed for a receiver other than what is inside the unit.

Selections	Explanation
Trimble SV6-CM3 – TSIP	Company Name: Trimble Model Number or Identifier: SV6-CM3 Communication Standard: TSIP (Trimble Standard Information Protocol)
Trimble Ace II – NMEA	Company Name: Trimble Model Number or Identifier: Ace II Communication Standard: NMEA (National Marine Electronics Assoc.)
Ashtech G8 – NMEA	Company Name: Ashtech Model Number or Identifier: G8 Communication Standard: NMEA (National Marine Electronics Assoc.)
Conexant Jupiter - NMEA	Company Name: Rockwell Model Number or Identifier: Jupiter Communication Standard: NMEA (National Marine Electronics Assoc.)
Furuno GN-80 - NMEA	Company Name: Furuno Model Number or Identifier: GN-80 Communication Standard: NMEA (National Marine Electronics Assoc.)

Send Position with ANI (Automatic Number identification)

Checking this box will cause a mobile that is equipped with an ANI (Automatic Numeric Identifier) to send its GPS position along with the ANI when the driver keys the microphone.

Send Position with RTT (Request to talk)

Checking this box will cause a mobile to send the GPS position information along with the drivers RTT (Request to Talk).

Send Position with Auxiliary

Checking this box will cause a mobile to send the GPS position information along with the status of the auxiliary input change.

Send Position with Emergency

Checking this box will cause a mobile to send the GPS position information along with an Emergency activation.

Send Position with Bar Code

Checking this box will cause a mobile to send the GPS position information along with a Bar Code read.

Send Position with Card Swipe

Checking this box will cause a mobile to send the GPS position information along with a Card Swipe transaction.

Compressed Sending

You must select the method of position reporting, called message generation type. Choices are timed sending, compressed timed, compressed event and MOTION-trak. Timed sending simply sends a position report at the programmed interval. Compressed timed collects position reports for a period of time, compresses them and sends them all at once. Compressed event collects position based on events such as stopping, starting, turning a corner and compresses them and sends them based on number of events and time. MOTION-trak sends position on a times basis, but the times change based on the status of auxiliary input 1 and if the vehicle is moving or stopped.

You may now select when you want the GPS information transmitted and a number of choices are provided.

You then select how often the GPS information is transmitted independently. Enter 1 for every minute, 2 for every 2 minutes etc. If you do not want the unit to transmit the GPS information automatically at regular intervals enter 120.

Timed Sending

Send Position Every

This selection determines the automatic reporting time interval. This value is in 1 minute increments, 0 = off.

NOTE: Depending on fleet size and system loading, too low of an entry here could result in system congestion which may effect voice communication. Select an interval that provides the level of updates required without causing unnecessary system traffic.

NOTE: Timed sending can be used in conjunction with the other 3 methods of reporting.

To do this, select and set up the Message Generation type desired i.e. Compressed Timed or Event. Then enter a value in minutes that you wish the unit to send a single update.

Compressed Sending

Compressed Timed logs the vehicle position on a programmable time basis then stores and compresses this information for a programmable period prior to sending the data.

Compressed Event logs the position based on movement and speed. The movement sensitivity (i.e., by how much and how long the movement took place, e.g. 20 degrees over 10 seconds etc) and speed parameters can be programmed.

The storage capability (buffer size) of the GPS-150 is 4000 bytes. Each location report requires 6 bytes. 320 bytes or roughly 50 location samples can be sent in one data transmission. Below is a chart that provides an idea of what should be expected from various timing parameters when using Timed Compressed Sending. Event Compressed cannot be predicted in this manner. It is possible to select timings that cause the buffer to fill before the time to send period is reached. In this case, the data transmission will occur when the buffer fills.

Generate Report Period	Time Between Sends	Number of Transmissions
30 Seconds	30 Minutes	2
30 seconds	60 Minutes	3
60 Seconds	30 Minutes	1
60 Seconds	60 minutes	2
120 Seconds (2 Min.)	60 Minutes	1
300 Seconds (5 Min.)	120 Minutes	1
600 Seconds (5 Min)	480 Minutes (8 Hrs.)	2

The following parameters apply to both compressed timed and compressed event sending.

Time Between Sends

Sets the time between compressed packet transmissions.

Compressed Timed Sending

Generate Record Period

Sets the time period between positions being logged for *Compressed Timed* generation. For example, if this parameter is set to 30 seconds and “time between sends” is set to 10 minutes, then up to 20 position messages will be logged and compressed into 1 packet and will be sent every 10 minutes.

Compressed Event Sending

Bearing Change

Sets the sensitivity of the bearing event detection. Lowering this number causes smaller changes in direction to be detected, such as minor turns, but also may cause more falsing on noise. Default is 20 degrees.

Bearing Time

Sets the amount of time that a bearing change must be maintained before considering it an event to be logged.

Stop / Start Time

Sets the amount of time a stop or movement must be maintained before considering it an event to be logged.

No Activity Time

Sets the amount of time to wait with no activity before logging a position report.

Peek Speed A

If this speed is exceeded, an event record is generated and logged.

Peek Speed B

If this speed is exceeded, an event record is generated and logged.

A detailed description of Compressed Sending setup can be found in CES product bulletin PB1527.

MOTION-trak™

Selecting MOTION-trak causes the TRK-240 to send vehicle location updates at different intervals based on movement. This is more efficient than “Timed” sending in that the reporting interval can be less frequent while the vehicle is not moving. An auxiliary input can also be used with MOTION-trak to obtain up to 4 possible reporting intervals. A good example of the auxiliary input usage would be, by connecting the auxiliary input to sense when the light bar of an emergency vehicle is on, and therefore increase the reporting interval when active.

Aux 1 inactive / active, Stopped / Moving

This chart sets the timed sending parameters for the various conditions or states.

State change guard time

Defines the time period in which a state change must be maintained before considering the change valid. In other words if this value is set to 1 minute, a vehicle that stops after previously moving for more than 1 minute, must be stopped for at least 1 minute before the reporting time changes. Thus a vehicle that has been sitting still for more than 1 minute must move continuously for more than 1 minute before changing to the moving reporting period.

Aux in 1

Used to enable aux in 1 and set polarity for use with MOTION-trak. By using this input, four different reporting intervals are available.

Datum

ACE

Sets datum for Trimble ACE module. Default of WGS-84 should typically not be changed.

Jupiter

Sets datum for Conexant Jupiter module. Default of WGS-84 should typically not be changed.

ANI / STATUS

Actual view may vary due to programs backward compatibility dependent on the firmware version.

ANI (Automatic Number Identification)

Leading

Enable this if it is desired that the ANI be sent at the beginning of a voice transmission. This is the method used in most applications.

Trailing

Enable this if it is desired that the ANI be sent at the end of a voice transmission.

Random

Enable this if it is desired that the ANI be sent at random intervals while PTT is active.

NOTE: Some radios may not support ANI without internal modifications. Consult CES Wireless for details.

Random Window Time

This selection determines the maximum amount of time that may elapse during a transmission without the ANI being sent. For example, if random ANI is on and the random ANI “window time” is 3 seconds, then an ANI will be sent randomly between 0 and 3 seconds. Programmable from 100-6000 in 10ms increments. Default is 500 (=5000ms).

ANI Holdoff

Count

This feature is used to set the number of times the PTT switch can be activated within a 30-second period without sending a new ANI. This feature is useful when you have fairly short back and forth conversations and don't want to keep sending the ANI with each PTT. Programmable from 0 - 25, 0=OFF, default is 0.

Reset Time

If the ANI holdoff count is 3 and the holdoff time is 20 seconds then on every 4th "PTT in" activation the ANI will be sent. If 20 seconds elapses then the next "PTT in" activation will cause an ANI to be sent. Programmable from 100 - 12000 in 10ms increments. Default is 3000 (=30000ms = 5min).

PTT Functions

Double Click

This selection when enabled causes a special command to be sent to the base dispatcher by double clicking on the radio microphone PTT switch. This is called RTT (Request To talk). This is typically only used with closed mode operation. See page 33 for explanation of Closed mode.

Stuck Mic

This selection sets the maximum amount of time that the radios PTT switch can be active prior to the TRK-240 sending the stuck mic status to the dispatcher. This setting should always be longer than the TX Limit timer. Programmable from 100 - 50000 in 10ms increments. Default is 12000 (=120000ms = 20min).

Note: This function may not work with some radio designs.

Guard Time

It is assumed that the user is not engaged in an active voice conversation if the TRK-240 does not see PTT activity for the PTT Guard Time period. If PTT Guard Time is enabled and the TRK-240 needs to send a transmission, it will wait this time period and monitor PTT activity. If there is any PTT activity during this time period, the TRK-240 will wait to send. This is used to prevent the TRK-240 sending data while the user is engaged in a voice conversation. Programmable from 0 - 12000 in 10ms increments. Default is 3 seconds.

TX Limit

This selection sets the maximum amount of time the transmitter can be active from local microphone activity before the TRK-240 sounds its alert and un-keys the transmitter (depending on radio wiring). The value entered should be shorter than the "Stuck Mic" value. Programmable from 0 - 50000 in 10ms increments. 0 = off. Default is 10000 (=100000ms).

TX Penalty

When the *transmit time out time* has elapsed, this setting defines the amount of time the PTT is locked out. If "PTT in" is activated before this time is up, an error tone is generated for as long as "PTT in" is held active. Programmable from 0 - 50000 in 10ms increments. 0 = No penalty. Default is 500 (=5000ms).

Disconnect PTT In from PTT Out

On most radios it is possible to get two functions from a single connection within the radio. The TRK-240 has a PTT out wire (to key the radio) and a PTT In wire (to detect local mic activity). In cases where the installation results in both wires connected to the same point, this checkbox should be enabled. This feature only applies to 'conventional', 'trunked' radio types.

Message Queue

Two types of messages can be sent, those that are placed in the **Long Term Queue** and those that are placed in the **Short Term Queue**. The main difference between the two is that the *long-term queue* will continue to send the message until an acknowledgment is received. The *short-term queue* will abort the send after the programmed number of retries and transfer the message to the *long-term queue*.

Status key activation

The *short-term queue* will try sending the message a limited number of times within a relatively short period of time. If no acknowledgment is received during these attempts, the send is aborted. The message is then transferred to the *long-term queue*. The *long-term queue* will do the same thing but if no acknowledgment is received the procedure timer begins. When this timer expires, the *short-term queue* logic is applied to attempt to send the frame again. This time will typically be from 10 to 60 minutes.

Long Term Queue

Procedure Time

Sets the amount of time to wait before sending a retry of a packet that is in the long term queue. Programmable from 5-240 minutes in 1 min increments. Default is 10 minutes.

Repeat Count

Sets the number of times to retry a packet that is not getting acked therefore keeps going into the *long term queue* when the procedure timer expires. Programmable from 1-1000. Default is 100.

Short Term Queue

Ack. Wait Time

Sets the amount of time to wait for an acknowledgment before applying the retry time window time to calculate when to send the next frame. Programmable from 100-12000ms in 10ms increments. Default is 200ms.

Repeat Count

Sets the number of times to retry sending long term frames in the standard queue before aborting the send and notifying the long term logic. Programmable from 1-1000. Default is 4.

Retry Window

This field currently has no function.

Remote Key Masking

Enable

Normally key masking is defined in the 'key tabs' section. Enabling remote key masking allows the mask set to be sent via a command from the base 'host' software, using the initial characters of a text message to change the mask settings for status keys. This feature requires compatible base software to operate correctly. This feature requires special firmware in the TRK-240 and is **not** supported by standard firmware.

Display / Audio Functions

Backlight

The LCD display backlight can be programmed to operate in a number of ways:

Selections	Explanation
Off Always	Off all the time
On Always	On all the time
On with Ignition Active	Ignition Sense must be enabled and connected
On with Activity (Factory Default)	The LCD back-lighting will come on when messages are received, status keys are activated etc.

Queue Size

This dictates the total number of messages the TRK-240 will store, programmable from 1-99

Alert Type

The TRK-240 generates audible alerts for specific events or actions such as receiving calls or pressing status keys. The standard TRK-240 is equipped with a piezo buzzer, and programmed with Buzzer as the alert source. The TRK-240 also has an audio output lead that could be connected to the radios audio PA to provide the alerts. (See the installation instructions for additional information)

Alert Time

Maximum amount of time to beep when a message is received. A setting of 0 will cause the unit to beep indefinitely. The beeping will automatically shut off if "PTT in" is activated. Programmable from 0-50000 in 10ms increments. 0 = infinity. Default is 1000 (=10000ms).

Disable Work Order Ack

This determines whether or not the driver must manually send an acknowledgement upon receipt of a Work Order message. In other words, push a status button dedicated for the purpose of indicating that the driver has read the Work Order message.

Status Keys

Status key operation

Twelve keys are provided on the front panel, in addition to the F1 and F2 keys. Text next to each key indicates the function. An LED near each key provides feedback as to which key is active and the acknowledgment state. When a status key is pressed, the LED will flash at a 1/4 second rate. When an acknowledgment is received it will illuminate steady. If the status transmission is not acknowledged and is placed in the “long term queue”, the LED will flash slowly until acknowledged. Pressing another key while a status is in Long term Queue will cause the Long Term Queue procedure timer to time out.

When any key that is active is pressed, the unit generates a chirp on the alert output. If a status action occurs because of a numeric key press, a double beep is generated.

The F1 and F2 keys are not programmable on a TRK-240. They normally act as display message **scroll up** and **scroll down**, except when a status key is activated and the TRK-240 is in “numeric mode”, they become **Abort** and **Enter** respectively. (Note: you can set the “numeric count” for 0 and use the F1/F2 keys are **Abort** and **Enter** during status activation’s)

The screenshot shows the TRK-240S configuration software interface. The title bar reads "TRK-240S - [TRK-240]". The menu bar includes File, Device, Configure, Program, Diagnostics, and Help. The toolbar contains buttons for Radio, Channel Change, I/O, Serial, GPS, ANI/Status, and a series of key function buttons (Key 1.2, Key 3.4, Key 5.6, Key 7.8, Key 9.0, Key *, #). The main window is divided into two panels, Key 1 and Key 2, each with the following settings:

- Key 1:**
 - Key Function: Status Key
 - Action To Take: None
 - Numerics Count Type: Fixed
 - Numerics Count: 5
 - When Action Occurs: ☒ Key Press, ☐ Ack Received
 - ☒ Send GPS With Status
 - ☒ Enable Status Numeric Entry
 - ☒ Enable Masking
 - ☒ Enabled At Power Up
 - ☒ Send Mileage with GPS
 - Odometer: ☐ Send, ☐ Reset
 - Keys Enabled After This One: ☐ Key 0, ☐ Key 1, ☒ Key 2, ☐ Key 3, ☐ Key 4, ☐ Key 5, ☐ Key 6, ☐ Key 7, ☐ Key 8, ☐ Key 9, ☐ Key *, ☐ Key #, ☒ Key F1, ☒ Key F2, Enable All, Disable All
- Key 2:**
 - Key Function: Status Key
 - Action To Take: None
 - Numerics Count Type: Maximum
 - Numerics Count: 0
 - When Action Occurs: ☒ Key Press, ☐ Ack Received
 - ☐ Send GPS With Status
 - ☐ Enable Status Numeric Entry
 - ☒ Enable Masking
 - ☐ Enabled At Power Up
 - ☐ Send Mileage with GPS
 - Odometer: ☐ Send, ☐ Reset
 - Keys Enabled After This One: ☒ Key 0, ☒ Key 1, ☒ Key 2, ☒ Key 3, ☒ Key 4, ☒ Key 5, ☒ Key 6, ☒ Key 7, ☒ Key 8, ☒ Key 9, ☒ Key *, ☒ Key #, ☒ Key F1, ☒ Key F2, Enable All, Disable All

Actual view may vary due to programs backward compatibility dependent on the firmware version.

Key Function

The following section describes the various key functions for all keys except (F1 & F2)

Selections	Explanation
None	Key is disabled
Status	Transmits Status message
Send RTT	Transmits Request to Talk Status
Send PRTT	Transmits Priority Request to Talk Status
Sends Emergency	Transmits Emergency Status
Spkr Mute Toggle	Mutes and Un-mutes the Radio Speaker

Numeric Count Type

This selection determines whether the value entered below under **Numeric Count** is the *maximum number* of entries the driver can make after activating a status key, or the *fixed number* the driver **MUST** enter. **Note:** When set to maximum the status can be sent without any additional entry.

Numeric Count

See Numeric Count Type. 0-25, default is 0.

Action to Take

This selection provides the ability for the TRK-240 to enter the “Open Mode” after sending a status. This selection is only applies if the TRK-240 is operating in the closed mode. Select “None” or “Enter Open Mode”. The Default is “None” See page 33 for explanation of Closed Mode.

When Action Occurs

Defines when the action associated with the key occurs. (This is for Closed Mode operation only)

1. *Key Press* - The action can occur immediately upon pressing the key.
2. *Ack Received* - The action will occur after the acknowledgment is received.

Send GPS With Status

When enabled, appends the GPS coordinates to a status transmission.

Enable Status Numeric Entry

The unit can be programmed to allow the user to enter numeric information after activating a status key. To enable this feature check here. This item must be enabled to display “Legends” (driver prompts).

Enable Masking

Every time a key is pressed the next keys that can be pressed are defined in ‘keys enabled after this one’ under the tab for that key. If enable masking is turned off then that key can always be pressed. For example with masking on, a company may want keys 2, 3 and 4 to always be pressed in succession but key 7 can be pressed anytime since 7 is ‘out to lunch’.

Enabled at Power Up

Specifies if the key is active on power up. For example, it might not be appropriate for a key that represents “Job Complete” to be available upon power up.

Send Mileage with GPS

When this is enabled, upon first power up, the TRK-240 begins accumulating mileage based upon GPS movement. This mileage value is appended to and sent along with the packet types listed below. This value is stored in non-volatile memory, and can only be reset by a command from the Host software.

1. (104) Status with position
2. (100) NMEA position
3. (103) Auxiliary Inputs with position
4. (108) Emergency with position
5. (132) Work order status with position
6. (133) Work order status response

Note: The mileage value is not included with compressed GPS sending (110)

Odometer

When selected includes an accumulated mileage based on GPS movement to the status packet. The TRK-240 starts accumulating mileage from 0, upon power up. The accumulated mileage is associated with the Status message as "STATUS DATA". This data is uniquely identified by a preceding ASCII carrot "^" character followed by the accumulated odometer value.

If the Status key is also configured to allow Status Numeric Entry by the driver, any manually entered STATUS DATA will be first in the string followed by the "^" and odometer value.

1. Enabling *Send* and *Reset* resets the mileage to 0 and then sends the status packet with the "^0000.0" status data.
2. Enabling *Send* only causes the accumulated mileage at that time to be sent with the status packet. The odometer field will continue to accumulate.
3. Enabling *Reset* only, resets the mileage to 0 when that Status key is pressed.

Keys Enabled after this one

Defines which keys can be pressed after this one is activated. This will only allow these checked boxes to be pressed after this key press if *Enable Masking* is enabled.

The screen shot on page 59 shows key 1 set up to be the only key available on power up, requiring a fixed 5 digit entry before the status can be sent and key 2 being the next available status key.

PREDEFINED MESSAGES

TRK-240s - [TRK-240 Predefined Messages]

File Device Configure Program Diagnostics Help

Predefined Messages

Line 1: Take Truck to Orlando Maintenance 34

Line 2: Yard for Routine Service 24

Line 3: 0

Line 4: 0

Message Number: 1

The TRK-240 has the ability to geminately store text messages. The purpose for this is to allow a dispatcher to cause a message to be displayed in a terminal without actually typing it. The text message is stored in 1 of 50 locations in the terminal. The dispatcher sends a command that signals the terminal which message to display. Each message can be up to 4 lines of 40 characters. This is more efficient than sending the actual text, in that it uses less air time.

Obviously this would be used in cases where the same messages are sent routinely.

Select the message number, and enter the desired text message. Then select “Program”, and “Send Unit Configuration” to store the message.

Select “Program” and “Get Unit Configuration” to read the Predefined messages.

Note: These messages cannot be altered by an over the air command.

A detailed description of predefined message setup can be found in CES product bulletin PB1523.

GEO-status

Up to 30 geo-STATUS™ can be programmed into the TRK-240. A geo-STATUS™ is a geographic region that is recognized by the TRK-240 and acted upon. The TRK-240 can be programmed to report on entry and/or exit of this region. Its upper left and lower right geographic coordinates define the box. A more detailed description of geo-STATUS™ setup can be found in CES product bulletin PB1524.

A status key with numeric attachment can be associated with a geo-STATUS™.

NOTE: Currently, the CES POWERtrak software will not process a geo-STATUS without a Status Key attachment.

Report Type

Selects how to report geo-STATUS™ state changes. Report on entry, exit or both.

Arm State

geo-STATUS™ can be armed or disarmed by the host software. **Not currently used.**

Latitude Upper Left

geo-STATUS™ are defined by upper left and lower right coordinates. Because of this all geo-STATUS™ are rectangles. Enter coordinates as degrees and decimal degrees. North is positive, south is negative, east is positive and west is negative.

Note: Entry of the coordinates is critical to the operation of the geo-STATUS™ feature. It is recommended that coordinate data come from the QUICK-trak™ or POWER-trak™ maps.

The formula for conversion of min/sec to decimal coordinates is:

1. Divide the minutes by 60;
2. Divide the seconds by 3600;
3. Add the 2 results to the degrees.

Example 35 degrees, 30 minutes , 30 seconds
 $30/60 = .500$
 $30/360 = .0083333$
 $35 + .5 + .0083333 = 35.5083333$

Latitude Upper Right – see above
Longitude Upper Left – see above
Longitude Upper Left – see above

When the GPS-150 recognizes that it has entered or exited a zone, it will send the status digit associated with that zone. The CES POWER-trak™ or 'host' software must be set up to interrupt the receipt of a status digit as an entry or exit of a zone. Because there may be more zones used than there are status digits, a numeric attachment can follow the status digit. A single Status digit or Status plus numeric attachment can represent zone entry or exit.

For example, if only one zone out of 30 will be used, then the status digit 1 could be used to represent entering zone 1 and a status digit 0 be used to represent exiting zone, with no numeric attachment. There are 11 possible status digits. If all 30 zones will be used, the programming would be something like this.

Zone Entry	Status Digit	Numeric Attachment	Zone Exit	Status Digit	Numeric Attachment
1 In	1	0	1 Out	1	1
2 In	1	2	2 Out	1	3
3 In	1	4	3 Out	1	5
4 In	1	6	4 Out	1	7
5 In	1	8	5 Out	1	9
6 In	2	0	6 Out	2	1
7 In	2	2	7 Out	2	3

Status on Enter

Enter the status key number to send when unit detects that it has entered a geo-STATUS™. The report type must be set to report on entry or both for this to work.

Status on Exit

Enter the status key number to send when unit detects that it has left a geo-STATUS™. The report type must be set to report on exit or both for this to work.


Numeric String Enter

If numerics are to be sent with the status key when a geo-STATUS™ has been entered then put them here.

Numeric String Exit

If numerics are to be sent with the status key when a geo-STATUS™ has been exited then put them here.

Hysteresis – Because there is some degree of instability in the GPS signal, the Hysteresis value aids in maintaining an In Zone state while a vehicle sits inside but near the edge of a GEO Zone. If a GEO zone is small enough that a vehicle may sit within 50 ft. of a zone wall, multiple In Zone reports may be generated. Below is graphic that illustrates the GEO Zone with Hysteresis.




Time in Zone – This field allows you to require that a vehicle be in a zone for a specified time period before it sends the zone information. This timer is also applied when exiting a zone.

TRK-240 LEGENDS

The TRK-240 can also be programmed with the ability to display key driven sub-menus. These sub menus could be used for 2 purposes. 1, to prompt the driver for additional numeric entries such as Enter Starting Mileage, Enter Job Number etc. or 2, as a drop down list of text messages that the driver can select from to cause a text message to be displayed by Power-trak.

Or for example, if status key 6 is designated Out of Service, the TRK-240 can be programmed to display a prompt when activated, e.g. 1=Breakdown, 2= Lunch, 3=Rest stop 4=End. The driver selects the appropriate sub-status and presses send.

12 different Legend fields, each 16 lines by 40 characters can be entered. Each is associated with a status key. If more than 1 legend is associated with the same status key then the legend for that key is lengthened. For example, if 2 sub-status screens are associated with status key 1 then the legend is 32 lines by 40 characters.



A detailed description of TRK-240 Legend setup can be found in CES product bulletin PB1525.

TRK-240 AUXILIARY INPUTS

The screenshot shows the TRK-240S configuration window for auxiliary inputs. It features a menu bar and tabs for Primary Setup, Condition Tables 1-3, and Condition Tables 4-6. The main area contains four input configuration panels, each with the following fields:

- Input 1:** Input Type: State Change, Power Up State: Ignore, State Change Type: Auxiliary, Auxiliary Action: Both. Send Mileage checkbox is unchecked.
- Input 2:** Input Type: None, Power Up State: Ignore, State Change Type: Auxiliary, Auxiliary Action: Lo to Hi. Send Mileage checkbox is unchecked.
- Input 3:** Input Type: None, Power Up State: Ignore, State Change Type: Auxiliary, Auxiliary Action: Lo to Hi. Send Mileage checkbox is unchecked.
- Input 4:** Input Type: None, Power Up State: Ignore, State Change Type: Auxiliary, Auxiliary Action: Lo to Hi. Send Mileage checkbox is unchecked.

Each panel also includes a 'Status Action' table with 'Status' and 'Numeric String' columns, and two rows for 'On Lo to Hi Send' and 'On Hi to Lo Send'.

The TRK-240 has 4 Auxiliary inputs. These inputs are typically used to sense events in the vehicle. Such as, Ignition On / Off, Door Open / Closed, and so on. These inputs trigger on a High versus Low signal, and can be programmed to trigger upon 3 conditions. High to Low transition, Low to High transition, or both. The auxiliary inputs **cannot** detect any conditions other than on or off, such as fluid levels or temperatures.

In addition, the auxiliary inputs can be connected to sensors for the purpose of detecting drum rotation and speed. This is primarily for the purpose of automatically detecting and sending status conditions for the Concrete Ready Mix industry. This manual does not describe the very involved setup for this.


The screenshot above shows auxiliary input 1 set up to send an auxiliary type packet upon both state changes of the input.

Input Type Selections

1. None = Disables the input
2. State Change = Sets the input to expect a simple state change
3. Low to High Pulse = Sets the input to expect pulses
4. High to Low Pulse = Sets the input to expect pulses


DIAGNOSTICS

From the Diagnostics menu you can test the I/Os, GPS receiver and radio status. The device firmware can also be changed via this menu.





Test Modes

Provides a complete test and diagnostics routine for the product.



GPS Test Mode

This provides the user with a capability to test the internal GPS board. The TRK-240 supports a number of manufacturer's models. Select the appropriate GPS receiver and click OK. From the factory, the TRK-240 will be programmed appropriately based on the receiver type originally installed. Read the unit to determine the appropriate selection.



Select "Get GPS Info" to retrieve the GPS data. It may be necessary to do this several times before getting a reading.



Radio Status

Select to view status of radio. Especially useful for digital radios such as GPRS or CDMA, displays received signal strength, network registration, etc.


Firmware

Provides for the rapid update of product firmware if major network changes or additional features are required.

Select this menu item to change the firmware version in the TRK-240. The firmware can be upgraded or downgraded. After the warning message, the “Open” window will come up allowing you to select the appropriate firmware version that you wish to upload. Once selected click on “Open” and it will bring up a window to upload your firmware. Depending on the software and firmware versions being worked with, you may be required to get the unit’s serial number before proceeding.



After the firmware has finished uploading, select “Verify Check Sum” to verify that the firmware was loaded successfully. The information box should indicate “Checksum’s are Equal”



Reset Unit

Resets the TRK-240 (same as cycling the power).

6.0 Local Diagnostic Mode

The CES WIRELESS TRK-240 has a keyboard accessible diagnostic mode. This diagnostic mode provides information about the status of its inputs and outputs, status of the received GPS signal (if equipped), the ability to test its outputs and program its many parameters.

To enter the Diagnostic mode, push and hold the # key and immediately press the F1 Key. This should bring up the Main Diagnostic Menu.

From the Main Menu the following selections are available.

Selecting an item from the main menu will bring up additional sub menus and options relating to that item.

1 = Radio Status	4 = View States	7 = Levels	0 = Exit
2 = Program Mode	5 = Identity	8 = Memory	
3 = Test outputs	6 = NMEA GPS	9 = Reset	

The following describes the selections and functionality available from the diagnostic mode.

1 Radio Status

The Radio Status screen indicates the Radio Type, System ID, Unit ID, Baud Rate and Lead in Delay that the unit is programmed for. It also indicates if it is on line or not for serial interfaced wireless units such as CDPD or GSM.

2 Program Mode

The TRK-240 has over 500 programmable items. The Program Mode allows individual items to be programmed. This is very useful for making simple changes like the unit ID or Lead in delay without the need for a computer. To make a change to an item, you must first enter the item number and then a value. The Item number represents the function being changed. The value represents the change being made. A complete list of item numbers and valid values can be found following this section.

To Program an Item

1. Enter the item number and press #
1 beep will be generated if the entry was valid, 3 beeps if entry is invalid.
The current value will now be displayed in the data field.
 2. Enter a new value if desired and push #, otherwise push * to abort.
If a valid entry was made 5 beeps will be generated, 3 beeps if invalid.
0# exits the Programming Menu.
- Note: Entering 255, as the item number will set the TRK-240 to factory defaults.

Lists of the supported programming items are shown following this section.

3 Test Outputs

The Test Outputs menu allows the activation of the Auxiliary and Radio interface outputs, testing of the

front panel Display and LED's as well as modem transmit functions.
The Following selections are available.

Modem Selections

Press 0 to Exit

1. Send Zeros:
2. Send Ones:
3. Send Dots:

Alert/Horn Selections

Press 0 to Exit

1. Alert Tone On:
2. Alert Tone Off:
3. Horn On:
4. Horn Off:

Display Selections

Press 0 to Exit

1. Show Keys on Display:
2. Cycle through LED's:
3. Backlight On:
4. Backlight Off:
5. Test LED:

Radio Output Selections

Press 0 to Exit

1. Speaker EN On:
2. Speaker EN Off:
3. Speaker Mute On:
4. Speaker Mute Off:
5. MIC Mute On:
6. MIC Mute Off:
7. PTT On:
8. PTT Off:

Aux Output Selections

Press 0 to Exit

1. Aux 1, 2, 3, R On:
2. Aux 1, 2, 3, R Off:

4 View States

The View States menu provides information about the condition of the Auxiliary and Radio inputs, Frame information and more.

The following selections are available.

Frame Selections

Press 0 to Exit

1. TX Requests:
2. RX Frames:
3. Num of TXs:
4. Num acks TXd:

System Selections

Press 0 to Exit

1. Stun/Revive
2. Stuck Mic
3. Diagnostic Jumper

User I/O Selections

Press 0 to Exit

1. Aux in 1: 2: 3: R:
2. Aux out 1: 2: 3: R:
3. Emergency State:
4. Emergency Error:

Radio Input Selections

Press 0 to Exit

1. Ignition:
2. PTT In:
3. Busy:

5 Identity

The Identity screen displays the following.

Product Firmware Version:

Product ID:

Electronic Serial Number:

Program ID:

Firmware Checksum:

6 NMEA GPS

This selection provides information about the internal GPS receiver (if equipped).

The following selections are available.

- | | |
|--------------|--|
| 1 = Show GGA | Displays, UTC, Latitude, Longitude, Signal Quality, Number of Satellites, etc. |
| 2 = Show GSA | Displays Receiver Mode, Fix Type, Satellite numbers, (PDOP, HDOP, VDOP) |
| 3 = Show RMC | Displays UTC, Status, Latitude, Longitude, Speed, Date, Checksum, etc. |

7 Levels (TRK-240 Version 2 Hardware only)

This selection provides the ability to set the Transmit and Receive data levels without the need to open the unit. *See “TRK-240 Level Adjustments” section for description of operation.*

Level Selections

Press 0 to Exit

- | | |
|----------------------|----------------------|
| 1. Increase TX Level | 3. Increase RX Level |
| 2. Decrease TX Level | 4. Decrease RX Level |

8 Memory (TRK-240 Version 2 Hardware only)

This selection is for CES Wireless diagnostics only.

Reset

Resets the unit and exits the Diagnostic mode.

Exit

Exits the Diagnostic mode.

7.0 List of Supported Keyboard Programming Items

Item	Description	Data Type	Range	Representation	Default
0	Exit program mode				
1	Group ID 1	Word	0 - 32767	0 = off	0
2	Group ID 2	Word	0 - 32767	0 = off	0
3	Group ID 3	Word	0 - 32767	0 = off	0
4	Group ID 4	Word	0 - 32767	0 = off	0
5	Group ID 5	Word	0 - 32767	0 = off	0
6	Group ID 6	Word	0 - 32767	0 = off	0
7	Group ID 7	Word	0 - 32767	0 = off	0
8	Group ID 8	Word	0 - 32767	0 = off	0
9	Group ID 9	Word	0 - 32767	0 = off	0
10	Group ID 10	Word	0 - 32767	0 = off	0
11	Unit ID	Word	1 - 32767		1
12	System ID	Byte	0 - 63		0
13	Radio type		0 - 3	0 = None 1 = Conventional 2 = LTR 3 = Smartnet	1
14	Lead in delay	Byte	0 - 200	10ms	50
15	Busy / request check	Word	1 - 2000	1ms	50
16	Request window	Word	1 - 200	10ms	50
17	Grant check	Word	1 - 200	10ms	20
18	Grant window>IDEN ID	Word	1 - 10000	10ms	200
19	Baud rate, Modem		0 - 2	0 = future use 600 1 = 1200 2 = future use 2400	1
20	Ack response time after decode	Word	10 - 6000	10ms	10
21	Time to wait for ack	Word	100 - 12000	10ms	200
22	Retry time window	Word	10 - 12000	10ms	500
23	Number of retries	Word	1 - 1000		4
24	Speaker enable polarity	Byte	0,1	0 = active lo, 1 = hi	0
25	Speaker mute polarity	Byte	0,1	0 = active lo, 1 = hi	0
26	Microphone mute polarity	Byte	0,1	0 = active lo, 1 = hi	0
27	Trunk polarity	Byte	0,1	0 = active lo, 1 = hi	0
28	Auxiliary in 1 filter	Byte	0 - 3	0 = disabled 1 = send on lo to hi 2 = send on hi to lo 3 = send on both	0
29	Auxiliary in 2 filter	Byte	0 - 3	0 = disabled 1 = send on lo to hi 2 = send on hi to lo 3 = send on both	0
30	Auxiliary in 3 filter	Byte	0 - 3	0 = disabled 1 = send on lo to hi 2 = send on hi to lo 3 = send on both	0
31	Auxiliary out 1 default power up state	Byte	0,1	Note 0 = active hi, 1 = active lo	1
32	Auxiliary out 2 default power up state	Byte	0,1	Note 0 = active hi, 1 = active lo	1

33	Auxiliary out 3 default power up state	byte	0,1	Note 0 = active hi, 1 = active lo	1
34	Emergency in filter	Byte	0 - 3	0 = disabled 1 = send on contact closed 2 = send on contact open 3 = send on both	0
35	Emergency supervisory filter	Byte	0 - 3	0 = disabled 1 = send on wire cut 2 = send on wire connected 3 = send on both	0
36	PTT in polarity	Byte	0,1	0 = active lo, 1 = hi	0
37	PTT out polarity	Byte	0,1	0 = active lo, 1 = hi	0
38	Enable auto-CALL™	Byte	0,1	0 = off, 1 = send RTT	0
39	Leading ANI	Byte	0,1	0 = off, 1 = on	0
40	Trailing ANI	Byte	0,1	0 = off, 1 = on	0
41	Random ANI	Byte	0,1	0 = off, 1 = on	0
42	Random ANI window time	Word	100 - 6000	10ms	500
43	ANI holdoff count	Byte	0 - 25	0 = off	0
44	ANI holdoff reset time	Word	100 - 12000	10ms	3000
45	Stuck microphone time	Word	100 - 50000	10ms	12000
46	Transmit time out time	Word	0 - 50000	10ms, 0 = off	10000
47	Transmit time out penalty	Word	0 - 50000	10ms, 0 = no penalty	500
48	Talk mode	Byte	0,1	0 = Open, 1 = Closed	0
49	Talk mode reset time	Word	10 - 50000	10ms	1000
50	Talk mode power up state	Byte	0,1	0 = Open, 1 = Closed	0
51	Call alert time	Word	0 - 50000	10ms, 0 = infinity	1000
52	Horn honk polarity	Byte	0,1	0 = active lo, 1 = hi	0
53	Ignition polarity	Byte	0,1	0 = active lo, 1 = hi	0
54	Honk horn when ignition inactive	byte	0,1	0 = off, 1 = on	0
55	Horn on time	Word	10 - 1000	10ms	100
56	Horn off time	Word	10 - 1000	10ms	100
57	Horn maximum on count	Byte	1 - 25		3
58	Encryption word 1	Word	0 - 65535		0
59	Encryption word 2	Word	0 - 65535		0
60	Encryption word 3	Word	0 - 65535		0
61	Aux Out R polarity	Byte	0,1	0 = active lo, 1 = hi	0
70	Max numerics to accept, status key 0	Byte	0 - 25	0 = none	0
71	Max numerics to accept, status key 1	Byte	0 - 25	0 = none	0
72	Max numerics to accept, status key 2	Byte	0 - 25	0 = none	0
73	Max numerics to accept, status key 3	Byte	0 - 25	0 = none	0
74	Max numerics to accept, status key 4	Byte	0 - 25	0 = none	0
75	Max numerics to accept, status key 5	Byte	0 - 25	0 = none	0
76	Max numerics to accept, status key 6	Byte	0 - 25	0 = none	0
77	Max numerics to accept, status key 7	Byte	0 - 25	0 = none	0
78	Max numerics to accept, status key 8	Byte	0 - 25	0 = none	0
79	Max numerics to accept, status key 9	Byte	0 - 25	0 = none	0
100	Channel Change, enable with open mode	Byte	0,1	0 = off, 1 = on	0
101	Alert type	Byte	0,1	0=tone, 1=buzzer	1
102	TX queue, long term, procedure time	Byte	1 - 240	minutes	5
103	TX queue, long term, repeat count	Byte	0 - 1000	count	100
104	TX queue, long term, time to wait for ack	Word	100 - 12000	10ms	200

105	TX queue, long term, retry time window	Word	10 - 12000	10ms	500
106	TX queue, short term, repeat count	Word	0 – 1000	count	2
107	Power up condition, status key 0	Byte	0,1	0 = disabled, 1 = enabled	1
108	Power up condition, status key 1	Byte	0,1	0 = disabled, 1 = enabled	1
109	Power up condition, status key 2	Byte	0,1	0 = disabled, 1 = enabled	1
110	Power up condition, status key 3	Byte	0,1	0 = disabled, 1 = enabled	1
111	Power up condition, status key 4	Byte	0,1	0 = disabled, 1 = enabled	1
112	Power up condition, status key 5	Byte	0,1	0 = disabled, 1 = enabled	1
113	Power up condition, status key 6	Byte	0,1	0 = disabled, 1 = enabled	1
114	Power up condition, status key 7	Byte	0,1	0 = disabled, 1 = enabled	1
115	Power up condition, status key 8	Byte	0,1	0 = disabled, 1 = enabled	1
116	Power up condition, status key 9	Byte	0,1	0 = disabled, 1 = enabled	1
117	Status Key 0, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
118	Status Key 0, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
119	Status Key 0, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
120	Status Key 0, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
121	Status Key 0, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
122	Status Key 0, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
123	Status Key 0, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
124	Status Key 0, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
125	Status Key 0, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
126	Status Key 0, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
127	Status Key 0, when action occurs	Byte	0,1	0 = key press, 1 = ack received	0
128	Status Key 0, action, talk mode	Byte	0,1	0 = key press, 1 = ack received	0
129	Status Key 1, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
130	Status Key 1, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
131	Status Key 1, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
132	Status Key 1, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
133	Status Key 1, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
134	Status Key 1, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
135	Status Key 1, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
136	Status Key 1, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
137	Status Key 1, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
138	Status Key 1, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
139	Status Key 1, when action occurs	Byte	0,1	0 = key press, 1 = ack received	0
140	Status Key 1, action, talk mode	Byte	0,1	0 = key press, 1 = ack received	0
141	Status Key 2, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
142	Status Key 2, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
143	Status Key 2, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
144	Status Key 2, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
145	Status Key 2, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
146	Status Key 2, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
147	Status Key 2, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
148	Status Key 2, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
149	Status Key 2, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
150	Status Key 2, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
151	Status Key 2, when action occurs	Byte	0,1	0 = key press, 1 = ack received	0
152	Status Key 2, action, talk mode	Byte	0,1	0 = key press, 1 = ack received	0
153	Status Key 3, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
154	Status Key 3, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
155	Status Key 3, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
156	Status Key 3, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
157	Status Key 3, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1

158	Status Key 3, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
159	Status Key 3, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
160	Status Key 3, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
161	Status Key 3, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
162	Status Key 3, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
163	Status Key 3, when action occurs	Byte	0,1	0 = key press, 1 = ack received	0
164	Status Key 3, action, talk mode	Byte	0,1	0 = key press, 1 = ack received	0
165	Status Key 4, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
166	Status Key 4, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
167	Status Key 4, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
168	Status Key 4, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
169	Status Key 4, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
170	Status Key 4, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
171	Status Key 4, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
172	Status Key 4, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
173	Status Key 4, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
174	Status Key 4, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
175	Status Key 4, when action occurs	Byte	0,1	0 = key press, 1 = ack received	0
176	Status Key 4, action, talk mode	Byte	0,1	0 = key press, 1 = ack received	0
177	Status Key 5, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
178	Status Key 5, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
179	Status Key 5, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
180	Status Key 5, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
181	Status Key 5, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
182	Status Key 5, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
183	Status Key 5, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
184	Status Key 5, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
185	Status Key 5, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
186	Status Key 5, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
187	Status Key 5, when action occurs	Byte	0,1	0 = key press, 1 = ack received	0
188	Status Key 5, action, talk mode	Byte	0,1	0 = key press, 1 = ack received	0
189	Status Key 6, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
190	Status Key 6, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
191	Status Key 6, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
192	Status Key 6, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
193	Status Key 6, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
194	Status Key 6, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
195	Status Key 6, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
196	Status Key 6, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
197	Status Key 6, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
198	Status Key 6, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
199	Status Key 6, when action occurs	Byte	0,1	0 = key press, 1 = ack received	0
200	Status Key 6, action, talk mode	Byte	0,1	0 = key press, 1 = ack received	0
201	Status Key 7, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
202	Status Key 7, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
203	Status Key 7, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
204	Status Key 7, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
205	Status Key 7, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
206	Status Key 7, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
207	Status Key 7, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
208	Status Key 7, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
209	Status Key 7, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
210	Status Key 7, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
211	Status Key 7, when action occurs	Byte	0,1	0 = key press, 1 = ack received	0

212	Status Key 7, action, talk mode	Byte	0,1	0 = key press, 1 = ack received	0
213	Status Key 8, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
214	Status Key 8, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
215	Status Key 8, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
216	Status Key 8, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
217	Status Key 8, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
218	Status Key 8, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
219	Status Key 8, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
220	Status Key 8, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
221	Status Key 8, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
222	Status Key 8, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
223	Status Key 8, when action occurs	Byte	0,1	0 = key press, 1 = ack received	0
224	Status Key 8, action, talk mode	Byte	0,1	0 = key press, 1 = ack received	0
225	Status Key 9, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
226	Status Key 9, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
227	Status Key 9, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
228	Status Key 9, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
229	Status Key 9, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
230	Status Key 9, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
231	Status Key 9, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
232	Status Key 9, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
233	Status Key 9, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
234	Status Key 9, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
235	Status Key 9, when action occurs	Byte	0,1	0 = key press, 1 = ack received	0
236	Status Key 9, action, talk mode	Byte	0,1	0 = key press, 1 = ack received	0
240	Send ANI with position	Byte	0,1	0 = disabled, 1 = enabled	0
241	Send RTT with position	Byte	0,1	0 = disabled, 1 = enabled	1
242	Send auxiliary in with position	Byte	0,1	0 = disabled, 1 = enabled	1
243	Send status with position	Byte	0,1	0 = disabled, 1 = enabled	0
244	Send position every	Byte	0 - 120	Minutes, 0 = off	0
255	Set all to factory defaults	Byte			
300	LCD backlight, power control	Byte	0 - 3	0 = off, 1 = on always, 2 = on when ignition active, 3 = on with unit activity	3
301	LCD message, max number to store	Byte	1 - 99		25
302	LCD message, alert time	Word	0 - 50000	10ms, 0 = infinity	15
303	Status key 0, function	Byte	0 - 5	0 = None, 1 = Status Key, 2 = Send RTT, 3 = Send PRRT, 4 = Send Emergency, 5 = Speaker Mute Toggle	1
304	Status key 1, function	Byte	0 - 5	Same as Item 303	1
305	Status key 2, function	Byte	0 - 5	Same as Item 303	1
306	Status key 3, function	Byte	0 - 5	Same as Item 303	1
307	Status key 4, function	Byte	0 - 5	Same as Item 303	1
308	Status key 5, function	Byte	0 - 5	Same as Item 303	1
309	Status key 6, function	Byte	0 - 5	Same as Item 303	1
310	Status key 7, function	Byte	0 - 5	Same as Item 303	1
311	Status key 8, function	Byte	0 - 5	Same as Item 303	1
312	Status key 9, function	Byte	0 - 5	Same as Item 303	1
313	Status key *, function	Byte	0 - 5	Same as Item 303	2
314	Status key #, function	Byte	0 - 5	Same as Item 303	5

317	Status key 0, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
318	Status key 1, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
319	Status key 2, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
320	Status key 3, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
321	Status key 4, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
322	Status key 5, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
323	Status key 6, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
324	Status key 7, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
325	Status key 8, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
326	Status key 9, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
327	Status key *, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
328	Status key #, numeric count type	Byte	0,1	0 = fixed, 1 = maximum	1
329	Status key F1, numeric count type	Byte	0,1	0 = fixed, 1 = max	1
330	Status key F2, numeric count type	Byte	0,1	0 = fixed, 1 = max	1
331	Status entry, accept numerics	Byte	0,1	0 = disabled, 1 = enabled	0
332	Power up condition, status key *	Byte	0,1	0 = disabled, 1 = enabled	1
333	Power up condition, status key #	Byte	0,1	0 = disabled, 1 = enabled	1
334	Power up condition, status key F1	Byte	0,1	0 = disabled, 1 = enabled	1
335	Power up condition, status key F2	Byte	0,1	0 = disabled, 1 = enabled	1
336	Status key *, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
337	Status key *, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
338	Status key *, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
339	Status key *, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
340	Status key *, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
341	Status key *, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
342	Status key *, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
343	Status key *, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
344	Status key *, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
345	Status key *, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
346	Status key *, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
347	Status key *, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
348	Status key *, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
349	Status key *, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
350	Status key *, when action occurs	Byte	0,1	0 = key press, 1 = ack	0
351	Status key *, action, talk mode	Byte	0,1	0 = none, 1 = enter open mode	0
352	Status key *, max keys to accept	Byte	0 - 25	0 = none	0
353	Status key #, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
354	Status key #, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
355	Status key #, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
356	Status key #, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
357	Status key #, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
358	Status key #, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
359	Status key #, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
360	Status key #, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
361	Status key #, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
362	Status key #, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
363	Status key #, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
364	Status key #, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
365	Status key #, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
366	Status key #, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
367	Status key #, when action occurs	Byte	0,1	0 = key press, 1 = ack	0
368	Status key #, action, talk mode	Byte	0,1	0 = none, 1 = enter open mode	0
369	Status key #, max keys to accept	Byte	0 - 25	0 = none	0

370	Status key F1, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
371	Status key F1, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
372	Status key F1, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
373	Status key F1, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
374	Status key F1, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
375	Status key F1, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
376	Status key F1, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
377	Status key F1, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
378	Status key F1, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
379	Status key F1, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
380	Status key F1, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
381	Status key F1, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
382	Status key F1, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
383	Status key F1, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
384	Status key F1, when action occurs	Byte	0,1	0 = key press, 1 = ack	0
385	Status key F1, action, talk mode	Byte	0,1	0 = none, 1 = enter open mode	0
386	Status key F1, max keys to accept	Byte	0 - 25	0 = none	0
387	Status key F2, enable key 0	Byte	0,1	0 = disabled, 1 = enabled	1
388	Status key F2, enable key 1	Byte	0,1	0 = disabled, 1 = enabled	1
389	Status key F2, enable key 2	Byte	0,1	0 = disabled, 1 = enabled	1
390	Status key F2, enable key 3	Byte	0,1	0 = disabled, 1 = enabled	1
391	Status key F2, enable key 4	Byte	0,1	0 = disabled, 1 = enabled	1
392	Status key F2, enable key 5	Byte	0,1	0 = disabled, 1 = enabled	1
393	Status key F2, enable key 6	Byte	0,1	0 = disabled, 1 = enabled	1
394	Status key F2, enable key 7	Byte	0,1	0 = disabled, 1 = enabled	1
395	Status key F2, enable key 8	Byte	0,1	0 = disabled, 1 = enabled	1
396	Status key F2, enable key 9	Byte	0,1	0 = disabled, 1 = enabled	1
397	Status key F2, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
398	Status key F2, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
399	Status key F2, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
400	Status key F2, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
401	Status key F2, when action occurs	Byte	0,1	0 = key press, 1 = ack	0
402	Status key F2, action, talk mode	Byte	0,1	0 = none, 1 = enter open mode	0
403	Status key F2, max keys to accept	Byte	0 - 25	0 = none	0
404	Status key 0, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
405	Status key 0, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
406	Status key 0, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
407	Status key 0, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
408	Status key 1, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
409	Status key 1, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
410	Status key 1, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
411	Status key 1, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
412	Status key 2, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
413	Status key 2, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
414	Status key 2, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
415	Status key 2, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
416	Status key 3, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
417	Status key 3, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
418	Status key 3, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
419	Status key 3, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
420	Status key 4, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
421	Status key 4, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
422	Status key 4, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
423	Status key 4, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1

424	Status key 5, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
425	Status key 5, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
426	Status key 5, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
427	Status key 5, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
428	Status key 6, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
429	Status key 6, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
430	Status key 6, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
431	Status key 6, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
432	Status key 7, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
433	Status key 7, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
434	Status key 7, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
435	Status key 7, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
436	Status key 8, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
437	Status key 8, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
438	Status key 8, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
439	Status key 8, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
440	Status key 9, enable key *	Byte	0,1	0 = disabled, 1 = enabled	1
441	Status key 9, enable key #	Byte	0,1	0 = disabled, 1 = enabled	1
442	Status key 9, enable key F1	Byte	0,1	0 = disabled, 1 = enabled	1
443	Status key 9, enable key F2	Byte	0,1	0 = disabled, 1 = enabled	1
444	Base IP Address 3	Byte	0 - 999	1 st set of 4 in TCP/IP Address	0
445	Base IP Address 2	Byte	0 - 999	2 nd set of 4 in TCP/IP Address	0
446	Base IP Address 1	Byte	0 - 999	3 rd set of 4 in TCP/IP Address	0
447	Base IP Address 0	Byte	0 - 999	4 th set of 4 in TCP/IP Address	0
448	CDPD, UDP Port	Word	0-65535		2100
449	GPS, Enable	Byte	0,1	0 = disabled, 1 = enabled	0
450	GPS, Communication Format	Byte	0 - 3	0 = Trimble SV6-CM3 – TSIP 1 = Trimble Ace II – NMEA 2 = Ashtech G8 – NMEA 3 = Conexant Jupiter – NMEA	3
451	Printer, Auto Eject	Byte	0,1	0 = disabled, 1 = enabled	1
452	NMEA GPS, Mask Latitude Polarity	Byte	0,1	0 = disabled, 1 = enabled	0
453	NMEA GPS, Mask Latitude	Byte	0,1	0 = disabled, 1 = enabled	0
454	NMEA GPS, Mask Longitude Polarity	Byte	0,1	0 = disabled, 1 = enabled	0
455	NMEA GPS, Mask Longitude	Byte	0,1	0 = disabled, 1 = enabled	0
456	NMEA GPS, Mask Time	Byte	0,1	0 = disabled, 1 = enabled	0
457	IDEN Base ID	String			0
458	Infosat, Base ID	String			0
459	Serial Port 1 assignment	Byte	0 – 4	0 = Programmer, 1 = Radio Interface, 2 = Card Reader, 3 = Printer, 4 = Keyboard	0
460	Serial Port 2 assignment	Byte	0 – 4	0 = Unused, 1 = Radio Interface, 2 = Card Reader, 3 = Printer, 4 = Keyboard	0
461	Serial Port 3 assignment	Byte	0 – 4	0 = Unused, 1 = Radio Interface, 2 = Card Reader, 3 = Printer, 4 = Keyboard	0
462	PTT guard time	Word	0 - 12000	10ms	0
463	Ignore busy when sending Acks	Byte	0,1	0 = disabled, 1 = enabled	1
464	Ignore busy when PTT is active	Byte	0,1	0 = disabled, 1 = enabled	1
465	Channel change timer 1	Word	0 - 65535	10ms	0

466	NMEA GPS, timed position send type	Byte	0 – 2	0 = Without Acks, 1 = With Acks 2 = With acks & Long term Q	0
467	Status key 0: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
468	Status key 1: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
469	Status key 2: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
470	Status key 3: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
471	Status key 4: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
472	Status key 5: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
473	Status key 6: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
474	Status key 7: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
475	Status key 8: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
476	Status key 9: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
477	Status key *: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
478	Status key #: enable masking	Byte	0,1	0 = disabled, 1 = enabled	1
479	Channel change, count	Byte	0 – 25	count	1
480	Channel change, timer 2	Word	0- 65535	10ms	0
482	Busy function	Byte	0 – 3	0 = Off, 1 = Before Channel Change, 2 = After Channel Change, 3 = Before and After Channel Change	3
483	Busy holdoff time	Word	1 – 65535	10ms	100
484	Busy polarity	Byte	0,1	0 = active lo, 1 = hi	0
485	Disconnect PTT in from PTT out	Byte	0,1	0 = disabled, 1 = enabled	0
486	Post channel change, count	Byte	0 - 25	count	1
487	Post channel change timer 1	Word	0 - 65535	10ms	0
488	Post channel change timer 2	Word	0 - 65535	10ms	0
489	Post channel change, when	Byte	0,1	0 = when frame is sent, 1 = After ack is received	0
490	Post channel change, type	Byte	0 – 3	0 = Off, 1 = Deactivate aux out R, 2 = Pulse aux out 1, 3 = Deactivate aux out 1	0
491	Pre channel change, when	Byte	0,1	0 = Before channel is accessed, 1 = After channel is accessed	0
492	Remote Key Mask Enable	Byte	0,1	0 = disabled, 1 = enabled	1
493	Radio, Base ID	String	0 – 14	string	0
494	Not Used				
495	Radio Service Center	String	0 – 14	string	0
496	Auxiliary In 4 (Ignition)	Byte	0 - 3	0 = off 1 = send on lo to hi 2 = send on hi to lo 3 = send on both	0
498	Acknowledgements, Perform channel change	Byte	0,1	0 = disabled, 1 = enabled	0
499	GPS, Message Generation Type	Byte	0 – 2	0 = Timed, 1 = Timed Compressed, 2 = Event	0
500	Compressed GPS, Event Sensitivity	Byte	1 - 15	Relative	3
501	Compressed GPS, Max time to hold frames	Word	1 - 65535	Minutes	15
502	Compressed GPS, Minimum time between sends	Word	1 - 65535	Minutes	5
503	Compressed GPS, Event no activity timer	Word	10 - 65535	Minutes	60

504	Compressed GPS, Period to generate records	Word	15 - 65535	Seconds	60
505	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
506	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
507	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
508	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
509	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
510	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
511	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
512	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
513	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
514	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
515	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
516	Status key 0, numeric entry enable	Byte	0,1	0 = disabled, 1 = enabled	0
590	GPS stopped, Aux in 1 inactive	Word	0 - 65535	Seconds	3600
591	GPS moving, Aux 1 inactive	Word	0 - 65535	Seconds	900
592	GPS stopped, Aux in 1 active	Word	0 - 65535	Seconds	3600
593	GPS moving, Aux 1 active	Word	0 - 65535	Seconds	900
594	State change guard time			Seconds	10
595	Aux in 1 (Motion-trak)				
596	Key # 1 Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
597	Key # 2 Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
598	Key # 3 Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
599	Key # 4 Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
600	Key # 5 Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
601	Key # 6 Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
602	Key # 7 Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
603	Key # 8 Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
604	Key # 9 Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
605	Key # 0 Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
606	Key * Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
607	Key # Send GPS with Status	Byte	0,1	0 = disabled, 1 = enabled	0
608	Comp. Event Peek speed A	Byte	0 - 255	Knots	200
609	Comp. Event Peek speed B	Byte	0 - 255	Knots	250
610	Decrement retries on channel access error	Byte	0,1	0 = disabled, 1 = enabled	0

611	Enable strip turnoff code on Aux out 1	Byte	0,1	0 = disabled, 1 = enabled	0
614	Speaker mute active during Ack wait time	Byte	0,1	0 = disabled, 1 = enabled	0
615	Speaker mute active during frame transmit	Byte	0,1	0 = disabled, 1 = enabled	0
616	Flash box report time	Word	1 - 65535	Seconds	15
617	Flash box Aux in 1	Byte	0,1	0 = disable 1 = enable	0
618	Aux in 2	Byte	0,1	0 = disable 1 = enable	0
619	Aux in 3	Byte	0,1	0 = disable 1 = enable	0
620	Aux in 4 (ignition)	Byte	0,1	0 = disable 1 = enable	0
621	Aux in	Byte	0,1	0 = disable 1 = enable	0
622	Emergency Supervisory	Byte	0,1	0 = disable 1 = enable	0
623	Key # 1 odometer Reset	Byte	0,1	0 = disable 1 = enable	0
624	Key # 1 odometer Send	Byte	0,1	0 = disable 1 = enable	0
625	Key # 2 odometer Reset	Byte	0,1	0 = disable 1 = enable	0
626	Key # 2 odometer Send	Byte	0,1	0 = disable 1 = enable	0
627	Key # 3 odometer Reset	Byte	0,1	0 = disable 1 = enable	0
628	Key # 3 odometer Send	Byte	0,1	0 = disable 1 = enable	0
629	Key # 4 odometer Reset	Byte	0,1	0 = disable 1 = enable	0
630	Key # 4 odometer Send	Byte	0,1	0 = disable 1 = enable	0
631	Key # 5 odometer Reset	Byte	0,1	0 = disable 1 = enable	0
632	Key # 5 odometer Send	Byte	0,1	0 = disable 1 = enable	0
633	Key # 6 odometer Reset	Byte	0,1	0 = disable 1 = enable	0
634	Key # 6 odometer Send	Byte	0,1	0 = disable 1 = enable	0
635	Key # 7 odometer Reset	Byte	0,1	0 = disable 1 = enable	0
636	Key # 7 odometer Send	Byte	0,1	0 = disable 1 = enable	0
637	Key # 8 odometer Reset	Byte	0,1	0 = disable 1 = enable	0
638	Key # 8 odometer Send	Byte	0,1	0 = disable 1 = enable	0
639	Key # 9 odometer Reset	Byte	0,1	0 = disable 1 = enable	0
640	Key # 9 odometer Send	Byte	0,1	0 = disable 1 = enable	0
641	Key # 0 odometer Reset	Byte	0,1	0 = disable 1 = enable	0
642	Key # 0 odometer Send	Byte	0,1	0 = disable 1 = enable	0
643	Key * odometer Reset	Byte	0,1	0 = disable 1 = enable	0
644	Key * odometer Send	Byte	0,1	0 = disable 1 = enable	0
645	Key # odometer Reset	Byte	0,1	0 = disable 1 = enable	0
646	Key # odometer Send	Byte	0,1	0 = disable 1 = enable	0
647	Aux in 1 Power Up State	Byte	0 - 2	0 = Low 1 = High 2 = Ignore	2
648	Aux in 2 Power Up State	Byte	0 - 2	0 = Low 1 = High 2 = Ignore	2
649	Aux in 3 Power Up State	Byte	0 - 2	0 = Low 1 = High 2 = Ignore	2
650	Aux in 4 Power Up State	Byte	0 - 2	0 = Low 1 = High 2 = Ignore	2
651	Enable Constant Speaker Mute	Byte	0,1	0 = disable 1 = enable	0
652	Auto Mute Duration	Word	0 - 65535	10 ms	20
653	Send Position with Emergency	Byte	0,1	0 = disable 1 = enable	0
654	Send Position with Bar Code Scan	Byte	0,1	0 = disable 1 = enable	0
655	Send Position with Card Swipe	Byte	0,1	0 = disable 1 = enable	0
656	Disable Work order Ack	Byte	0,1	0 = disable 1 = enable	0

Specifications

Mechanical

Dimensions:	8.5 x 5.3 x 1.8 inch (10.16x10.16x3.8 cm)
Weight:	3.50 lb (1.40kg)
Cabinet:	Steel
Interface Cable:	3 ft shielded / factory sealed connector
Hardware:	Mounting bracket/screws

Electrical

Voltage:	8-16 V DC
----------	-----------

Current:	Standby: 250ma. Backlighting On: 560ma. (No GPS Receiver)
Current:	Standby: 300ma Backlighting On: 630ma. (With GPS Receiver)
Current:	Standby: 300ma. Backlighting On: 610ma. (With CDMA & no GPS Receiver)
Current:	Standby: 360ma Backlighting On: 670ma. (With CDMA & GPS Receiver)
Current:	Standby: 300ma. Backlighting On: 600ma. (With GPRS & no GPS Receiver)
Current:	Standby: 340ma Backlighting On: 650ma. (With GPRS & GPS Receiver)
Microphone Muting	Open Collector
PTT Output	Open Collector
Speaker Mute Output	Open Collector
Horn Alert Output	Open Collector
Auxiliary Inputs	Z=100K -35 to +35V
Auxiliary Outputs	Open Collector
Emergency input	0-5V connect to ground via switch
Ignition Sense	Z=100K -35 to +35V
Encode Tone O/p Imp.	Z=47K or 10K cap coupled
Encode Tone O/p Level	1 Volt RMS (variable)
Signal Input Sensitivity	100-1000mv RMS (variable)
Signal Input Impedance	Z=67K or 20K cap coupled
Alert Tone O/p Impedance	Z=67K or 20K cap coupled
Alert Tone Output Level	1.5V RMS (variable)

Signaling

Format	MSK 600/1200/2400/3800/4800 baud
Programming	TRK-240S Windows Software

Environmental

Operating temperature	0 to + 50 deg. C (+32 to +122 deg. F)
Storage temperature	-20 to + 70 deg. C (-4 to +158 deg. F)

Display

LCD	4 x 40 Character, backlit, Super Twist Nematic
-----	--

LED

Rated 50,000 hours

- Each Status has a built in LED to report progress
- 7 Segment LED verifies key press
- Keypad LED backlit

Ordering

TRK-240	Mobile Status/Display Terminal
TRK-240/01	Radio Interface harness
TRK-240/01	Auxiliary Interface harness
TRK-240/04	Label - Numeric
TRK-240/03	Label- Taxi
TRK-240/02	Label - Readymix
TRK-240/08	Label- Aggregate
TRK-240/09	Label - Custom
SHLD-120	Sun Shield
GPS-120	GPS Module & installation kit
ANT-01	GPS Antenna (Magnet Mount)
ANT-02	GPS Antenna (Permanent Mount)
CRD-500	Credit Card Reader
PNT-97	Mobile Printer
KBD-97	External QWERTY Keyboard
TRKD-240	Dealer Demonstration System w/o GPS
TRDDG-240	Dealer Demonstration System with GPS
CD-SOFT1	Programming Software Windows 98, 2000 & XP English
ARI-199P	Programming Interface Adapter (for Hardware version 1 only)
TRKPGMR	Programming Interface Adapter for Hardware version 2
TRAN21	110V AC Adapter (for ARI-199P)
CONV01	DB-9 to DB25 Adapter (for ARI-199P)
MANUAL104	Programming & Installation Manual

9.0 In Case of Difficulty

In Case Of Difficulty

Module appears to be inoperative, although programming was successful.

- (1) Ensure that the power and ground connections are properly connected.
- (2) Verify that PTT Input and PTT Output connections are correct.
- (3) Verify correct PTT Input and Output logic by reading the terminal configuration.
- (4) Verify that the Busy or Trunking Input is operating correctly, and that the appropriate active logic level is programmed in the *TRK-240*.

Unit is sending an ANI of the correct type but is not being decoded at the point of dispatch.

- (1) Verify in the dispatch software setup has been validated to receive this ANI.
- (2) Verify with a service monitor that the encoded level is set correctly. If set too high the modulated tones may be clipped or distorted. Readjust R34 on the *TRK-240* Terminal as necessary to correct.
- (3) Get Unit Configuration by reading the Tracker II with the PC software.
- (4) Review the Lead In Delay as set in the module. This particular radio may require a longer period of time before sending the ANI.

If you need to call CES WIRELESS for HELP

Call 407-679-9440, and ask for product support.

Product support may ask you to **PRINT** a copy of the programmed parameters, and fax to CES WIRELESS for analysis. To do this, go to **FILE** on the TRK-240S main menu, and click on **PRINT**.

Have information available on:

- ♦ The type of radio transceivers in use
- ♦ The configuration of the radio system
- ♦ Setup of the base controller or base display console
- ♦ Details of the repeaters or line control in use


10.0 Amendments

April 7, 1998


Serial interfaces are customized based on the non-CES WIRELESS product to which we interface. To complete such an interface, we require the communications protocol information, together with an overview of the equipment functional expectations.

11.0 Circuit Diagram

12.0 Parts Location



Version 1



TRK-240 REV. 2 BOARD LAYOUT

Version 2